

proNAS 3.6

Configuration Guide

Revision 1.0

Table of Contents

Preface	4
Chapter 1 Introduction	5
1.1 Key Features.....	5
1.2 Technical Specifications.....	6
Chapter 2 Getting Started With proNAS 3.6	9
2.1 Prepare to Setup NAS	9
2.2 Login NAS Management Webpage by Using Web Browser	9
2.3 Setup and Installation.....	11
2.3.1 Quick Setup	11
2.3.2 Manually Initializing the NAS Step by Step.....	13
2.4 Connecting to the NAS Share Folder via Network	15
Chapter 3 System Management.....	17
3.1 Basic Layout of NAS Management GUI.....	17
3.2 Top Shortcut Bar	19
3.3 System Monitoring.....	21
3.3.1 System Information	21
3.3.2 Resource Monitor.....	22
3.3.3 System Log	23
3.4 System Manager	24
3.4.1 General.....	24
3.4.2 Network.....	26
3.4.3 UPS	34
3.4.4 Event	35
3.4.5 Power.....	38
3.4.6 Upgrade.....	39
3.4.7 Tools.....	40
3.4.8 Schedule Manager.....	41
3.5 Storage Manager.....	43
3.5.1 RAID / Array Manager	43
3.5.2 Volume Group Manager	47
3.5.3 iSCSI Manager	56
3.5.4 FC Manager.....	60
3.5.5 Share Manager.....	63
3.6 Service Manger	73
3.6.1 Samba service	73
3.6.2 NFS service	75
3.6.3 AFP service	76

3.6.4	FTP service	77
3.6.5	WebDAV service	78
3.6.6	TFTP service.....	79
3.6.7	Rsync service.....	79
3.6.8	Bonjour service	80
3.6.9	SNMP service.....	81
3.6.10	DHCP service	82
3.6.11	SSH service	83
3.6.12	Telnet service	83
3.6.13	File Manager	84
3.7	Account Manager	85
3.7.1	Account	85
3.7.2	Group.....	91
3.7.3	Directory Service	94
3.8	Backup Manager	97
3.8.1	Data Backup.....	97
3.8.2	Data Copy	104
3.8.3	Replication Backup	108
3.8.4	Snapshot Backup	113
3.8.5	Volume Clone	118
3.8.6	Rsync Backup	120
3.8.7	System Configuration	122
3.8.8	Amazon S3	123
3.9	Attached Device Manager	126
3.9.1	Physical Device	126
3.9.2	ISO Mount	127
3.9.3	iSCSI Initiator	128
3.10	Plug-in Manager.....	130
3.10.1	NAS HA.....	133
3.11	File Manager	148
3.12	General Limitation List	152

Preface

About this manual

This manual provides information regarding the configuration of the **NAS 3.6 System**. This document also describes the use of the storage management software. Information contained in the manual has been reviewed for accuracy, but not for product warranty because of the various environment/OS/settings. Information and specifications will be changed without further notice. Some pictures and screenshots might be different with the actual machine.

This manual uses section numbering for every topic being discussed for easy and convenient way of finding information in accordance with the user's needs. The following icons are being used for some details and information to be considered in going through with this manual:



NOTES:

These are notes that contain useful information and tips that the user must give attention to in going through with the subsystem operation.



IMPORTANT!

These are the important information that the user must remember.



WARNING!

These are the warnings that the user must follow to avoid unnecessary errors and bodily injury during hardware and software operation of the subsystem.



CAUTION:

These are the cautions that user must be aware of to prevent damage to the equipment and its components.

Copyright

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent.

Trademarks

All products and trade names used in this document are trademarks or registered trademarks of their respective owners.

Changes

The material in this document is for information only and is subject to change without notice.

Chapter 1 Introduction

1.1 Key Features

- Account Manager support NIS
- Allows online capacity expansion within the enclosure
- Android/iOS mobile APP for monitoring
- Backup to Cloud (Amazon S3)
- Backup/Restore from attached storage (USB/eSATA/iSCSI/RDX/USM)
- Backup/Restore from remote share (CIFS/NFS)
- Bonjour Protocol, easily connect to NAS
- Compression (Support on ZFS file system)
- Central data and storage management
- Data backup via backup plan/schedule
- Data copy (1:1)
- Deduplication (Support on ZFS file system)
- EXT4 support extend over 16TB
- HA support Active-Active mode
- HA support iSCSI/FC volume
- HA support Three nodes
- iSCSI/FC/share volume replication
- ISO mount
- Latest volume snapshot technology
- Local and external account management, support large account import
- Online expansion file system
- Plug-in management
- Select share or file for backup/restore
- Share management and permission (support ACL setting)
- Support Fiber target for Fiber SAN (Optional)
- Support Internet Gateway
- Support iSCSI target for IP SAN
- Support iSCSI initiator
- Support iSCSI multi host
- Support e-mail notification, SNMP Trap/MIB and system log
- System configuration backup/restore
- SSD Caching (Read cache, Support on ZFS file system)
- Thin Provisioning
- Volume Clone (EXT3/EXT4/XFS/NTFS/VMFS/ZFS)
- Volume replication to enhance data protection
- Volume switch between iSCSI and FC Target
- VMware ESXi 5 iSCSI/FC/NFS VAAI support
- Wizard-oriented GUI design
- WORM (Write Once Read Many) support CIFS/NFS

1.2 Technical Specifications

NAS Functionality
Storage Management
Volume management (Support ZFS, XFS, EXT3 and EXT4 file system)
Support SSD Caching, Compression and Deduplication (Support on ZFS file system)
Disk usage statistics
Hot spare drives
iSCSI Target manager: Support LUN Mapping/Initiator Filter/Thin Provisioning
FC Target manager: Support LUN Mapping/Thin Provisioning
VAAI support for iSCSI/FC/NFS
General
Independent file server
Multiple language support
Support UPS
Support LV encryption
System Management
Automatic IP address configuration
Web browser-based management
SNMP management and notification
Fail-free online firmware upgrade
Unicode support
Multi-node management GUI
System configuration backup/restore
Central management
Quick wizard
APP for Android/iOS monitoring
Networking
Support NIC/Trunking/Load Balance/Fail Over/802.3ad
DHCP Server/DHCP Client
WINS Server
Internet gateway
DDNS

Protocols
TCP/IP, SMB/CIFS, NFS, SNMP, FTP/SFTP/FXP, HTTP, HTTPS, Telnet, SSH, AFP, WebDAV, Bonjour, TFTP
Client Operating Systems Support
Microsoft® Windows® 98/ME/NT/2000/XP/2003/Vista/2008 /Win7/Windows 2012/Win 8
Unix/Linux
Mac OS
Authentication
Local user account/group
Microsoft NT Domain Controller (PDC)
Microsoft Active Directory Authentication (ADS)
Network Information Service (NIS)
Support OpenLDAP service
Support creating users by batch
User quota management
Share level security
File level security
User ID security for NFS
Recycle bin (Samba)
File access log, audit (Samba)
Write Once Read Many (WORM)
Block Storage
iSCSI Target Support
Fiber Target Support (optional)
Thin Provisioning support
VMware VAAI support
Virtualization
VMware/Citrix/Hyper-V
VMware VAAI for NFS support
Attached Storage
ISO Mount
USB/eSATA*/iSCSI initiator
Data Backup / Restore
Volume Clone (EXT3/EXT4/XFS/NTFS/VMFS/ZFS)
Symantec BackupExec Agent (by additional installation)

Scheduling multi-snapshot (Support iSCSI & FC snapshot)
Replication (Remote realtime data mirroring)
proNAS High-Availability (Three(3) nodes HA Cluster)(optional)
Scheduling Rsync Replication
Support NetVault backup client (by additional installation)
Support CA ARCserve (by additional installation)
Data copy (copy files to other share/attached storage)
Scheduling backup
Differential/incremental backup
iSCSI/FC Replication
Amazon S3 backup
backup/restore from attached storage (USB/eSATA*/iSCSI/RDX*/USM*)
Support Apple Time Machine
Plug-in management
Anti-Virus
Central management
iTunes Server
Virtualization (VM on NAS)

* By OEM request

Specification are subject to change without notice.

All company and product names are trademarks of their respective owners.

Chapter 2 Getting Started With proNAS 3.6

2.1 Prepare to Setup NAS

1. Before power on, make sure all power cables are plugged.
2. Check that LAN cable is connected to LAN_0 port of NAS and is linked.
3. To initialize the system, at least one hard drive is needed and inserted in the drive slot.



NOTE: Compatible List of Hard Drive Models

NAS product supports major hard drive brands of 2.5-inch and 3.5-inch SAS / SATA hard drive. Please check Unifosa website:

<http://www.proware.com.tw> for the latest hard disk drives compatibility list for the NAS.



Important Reminder: Unifosa will not be responsible for any data loss due to incorrect installation or use of hard drive and caused damage to the product under abnormal operation.



Warning: When hard drives that have never been used in the NAS are installed, the hard drives will be formatted automatically when Array is created, and existing data on the hard drives will be cleared.

2.2 Login NAS Management Webpage by Using Web Browser

After power on, please wait for about one minute to boot the system, then the NAS can be managed via web browser at any Windows, Linux, or Mac OS client.

1. Open web browser, input **http://<NAS-IP>** in URL bar.

For example: <http://172.16.0.1>

**NOTE:**

- A. The NAS default IP address is **172.16.0.1**.
- B. If NAS is set as a DHCP client or you are not sure what IP is used by the NAS, please check the front panel LCD to know the current IP address.
- C. Make sure the NAS and the client PC (that you will use to manage the NAS) are on the same subnet.
- D. The recommend browsers for management are Google Chrome and Firefox.

2. When the login page (Figure 2.2.1) is shown, input user name "**admin**" and password (default) "**00000000**". To select the operating language of the management page, select your preferred language on the drop-down list box on the right side.



NOTE: The default admin password might be different in some NAS. Please ask your NAS vendor if you have problem to logon.




Figure 2.2-1 Login page

3. After login, you will see the main NAS management GUI (Figure 2.3.2-1). You can now start to manage or setup the system.
4. By default, SSL login is enabled in NAS and allows users to configure and manage the NAS via encrypted transmission. To use this function, you can open the browser then input **https://<NAS-IP>** in URL bar.

For example: <https://172.16.0.1>



NOTE: If the NAS is behind NAT router or firewall and will use SSL login and remote access from the Internet, open NAT or firewall port 443 to direct to the LAN IP of NAS.

2.3 Setup and Installation

All NAS services and functions are disabled without first initializing the NAS. There are two way to initialize the NAS, by using Quick Initialization feature or manually step by step.

2.3.1 Quick Setup

After login as "admin" and NAS has not been initialized yet, GUI will pop up a message to ask you to use Quick Initialization feature (Figure 2.3.1-1) to setup the system. The Quick Initialization feature helps you to initialize the NAS in just one page setup. To setup using "NAS Quick Initialization", click "Yes". Then you can start to quickly setup the NAS by providing some information and setting some options, as shown in Figure 2.3.1-2.

If you do not want to use Quick Initialization feature, click "**No**" in Figure 2.3.1-1. Please note that many functions will be disabled without first initializing the NAS. The Options of Quick Initialization page list next page.




Figure 2.3.1-1 The confirm message to use Quick Initialization

Figure 2.3.1-2 NAS Quick Initialization page

Network

Please modify the options here to match your network environment.

Dynamic IP	When enabled, this set the NAS as DHCP client (not suggested)
Host Name	Set a unique host name for NAS to be used in network environment.
IP address	Set a static IP for LAN_0. (Usually for client connection)
Gateway	Set gateway IP for LAN_0.
Subnet Mask	Set the Subnet Mask for LAN_0.

Array

The NAS must have at least one Array in order to initialize the system.

Array Name	It is fixed to "Array01" for the first Array.
Create Spare	Enable this option to reserve a hard drive as a spare disk for Array.
Level	Select the RAID Level. Quick Initialization only support RAID levels 0,1,5 and 6.
Disk Number	The total number of hard drives detected by the system.
Free Size	The estimated size of the Array after it is created.



NOTE: All disks will be the member of Array01. If you plan to create the Array manually, please exit (Cancel) the Quick Initialization and read the Chapter 2.3.2.

Logical Volume

Create a network share folder with specified size for users.

- Home Size(GB)** The default reserved space for user's home folder
- Share Name** The share folder name that will be accessible to users in the network
- Share Size(GB)** The volume size of the share folder

Service

Decide which services need to be enabled after setup, and allow users to connect and access the network share folder(s).

- Window(Samba)** Select this service to enable access for Window users.
- Unix(NFS)** Select this service to enable access for Unix users.
- Apple(AFP)** Select this service to enable access for MAC users.

After filling up all options, click "**OK**" to execute the setup. This only takes about one minute. After setup is completed, you need to re-login the GUI and customize the detailed configuration. Meanwhile, user can access the share folder via network now.

2.3.2 Manually Initializing the NAS Step by Step

If you would like to create the Array manually, please click "**No**" in Quick Initialization page (Figure 2.3.1-1). After that, you will see the main NAS information page as shown in Figure 2.3.2-1. Then select "**Storage Manager**" and "**RAID**" (refer to Section 3.5.1), and click "**Add**" to create a customized Array. After Array is created, follow the GUI wizard that will take you to setup NAS by creating Volume Group, Logical Volume, Share or iSCSI step by step.

PRONAS

System Information

Model Information

Host Name : NAS
 Version : 3.0.00-test (2013/04/29 14:54)
 CPU : Intel(R) Xeon(R) CPU E5-2403 0 @ 1.80GHz
 Memory : 4 GB

EN-3163S6T-RQX

Network Status

Interface	Status	IP	Subnet Mask	Gateway	MTU	MAC	Speed/Mode	DHCP
LAN_0	✓	192.168.100...	255.255.255.0	192.168.100...	1500	00:e0:81:df:0...	1000 Mb/s	✗
LAN_1	✗				1500	00:e0:81:df:0...	0 Mb/s	✓

Hardware Status

RAID ✓ CPU ✓ DISK ✓ FAN ✓ POWER ✓ TEMP. ✓

Service Status

Samba ✓ NFS ✓ AFP ✓ FTP ✓ WebDAV ✗ TFTP ✗ Rsync ✗ Bonjour ✗

SNMP ✗ DHCP ✗ SSH ✓ Telnet ✓ File Manager ✓

Multi Node List +

Figure 2.3.2-1 NAS main information page



NOTE: For more information about creating Array, please see Section 3.5.1.

2.4 Connecting to the NAS Share Folder via Network

After NAS is initialized, users can access the share folder from a client PC. Here are the steps to access NAS share folder from clients with different platforms.

Windows Users (SMB/CIFS)

Steps to connect to a NAS share folder:

1. Two options to connect to NAS shared folder:
 - a) Open Network Neighborhood and search Workgroup. If you can't find NAS, search the entire network, double-click the mouse on your workgroup, search for the NAS hostname, and double-click the mouse to connect the NAS.
 - b) Use the Run function in Windows OS, and enter \\NAS-hostname or \\NAS-IP to connect to NAS. For example: [\\NAS](#) or [\\172.16.0.1](#)
2. Enter a valid user name and password:

User name: admin

Password: 00000000
3. Select the share folder which you want to connect to.
4. You can start to use the NAS share folder, and you can also map the share folder as network drive.

Mac OS Users (SMB or AFP)



NOTE: If AFP is used, make sure AFP is enabled in Service Manager and in Share Protocol.

Steps to connect to a NAS share folder:

1. Click 'Go' > 'Connect to Server'
2. Use the following methods to mount the NAS share folder:

Using SMB, input: smb://NAS-IP or smb://NAS-hostname

Using AFP, input: afp://NAS-IP

For example: smb://172.16.0.1 or afp://172.16.0.1
3. Click 'Connect'

4. Enter a valid NAS user name and password (with permission to the share folder),

User name: admin

Password: 00000000

5. Click 'Connect'

6. Select the NAS share folder you want to be mounted on Mac, and click 'OK'.

Linux Users (NFS)

Steps to connect to a NAS share folder:

Execute the following command in client Linux console:

mount -t nfs <NAS IP>:/<Path-To-NFS-Share-Folder> <Directory to Mount>

Example:

NAS IP address: 172.16.0.1

Path to NFS Share Folder: /vol/LV_2/nfsshare

Directory to Mount: /mnt/share1

Use the following sample command on the Linux client computer:

```
mount -t nfs 172.16.0.1:/vol/LV_2/nfsshare /mnt/share1
```

To check the NAS NFS export list (path to NFS share folders), execute from console of Linux NFS client computer:

```
showmount -e <NAS-IP>
```

Example:

```
showmount -e 172.16.0.1
```



NOTE: On the Linux NFS client computer, you must be logged on with the root privileges to be able to mount successfully.

After mounting network share folder of NAS, you access the data on the mounted directory.

Chapter 3 System Management

3.1 Basic Layout of NAS Management GUI



There are 3 parts of the basic layout of NAS GUI, see Figure 3.1-1.

Part 1. Top Menu:

Shortcut Bar contains shortcut buttons of commonly used functions for quick access. Shortcut icon for System Log, File Manager, Buzzer, all APP list and Logout.

Part 2. Left Tree:

App Search: To find out a particular application or function, type the text to search for.

App List: All NAS functions are listed as tree view. You can click  or click  to expand tree view of all function tree.

Multi Node List: As shown in Figure 3.1-2, this lists all detected NAS that are in the same subnet. QLaunch can be downloaded here. QLaunch is a tool to scan and discover all NAS systems in the network.

Part 3. Right Content: This shows the NAS status and settings and configuration options.




Figure 3.1-1 Basic NAS GUI Layout




Figure 3.1-2 Multi Node List

You can click "<<" between the tree view and content view (on the upper side) to hide the left tree and change the content view into full mode for better viewing, in some case like viewing in tablet device. (Figure 3.1-3). Click ">>" to change back to normal view.




Figure 3.1-3 Hide the tree view list









3.2 Top Shortcut Bar



Figure 3.2-1 Shortcut Bar

Administrators can place frequently used functions in the shortcut bar for quick access.

Default functions in top Shortcut Bar

Icon	Function	Description
	Quick Wizard	Wizard that can be used to setup NAS functions quickly
	Information	For viewing the NAS information and status
	Resource Monitor	For checking the usage of system resources
	Array Manager	For creating/editing Array
	Volume Manager	For creating/editing Volume
	Share Manager	For create/editing Share folder
	Account Manager	For creating/editing Account
	Backup Manager	For creating/editing Backup Plan

Modifying Shortcut Functions in the Shortcut Bar






To Add:

Select the function on the left tree (App List), drag and drop the icon to the top Shortcut Bar. The selected function will be automatically added in the Shortcut Bar. Please note that the maximum number of shortcut icons that can be placed on the Shortcut Bar is 9.

To Remove:

On the Shortcut Bar, press and hold your mouse button on the function icon and drag the mouse cursor anywhere to the right. The selected function will be automatically removed from the Shortcut Bar. Please note that "Quick Wizard" cannot be removed.

There are some small shortcut icons on the top right side of the GUI. There icons are system default and cannot be modified.

Icon	Function	Description
	System Log	For viewing system logs (see Section 3.3.3)
	File Manager	This icon enables "admin" user to redirect to the File Manager web page (see Section 3.11)
	Buzzer	This is used to enable/disable alarm beeper when hardware event occur.
	Home	Show all App List to easily find all functions. (Figure 3.2-2)
	Logout	Exit the management GUI



NOTE: If you do not logout by clicking the Logout icon, you will not be allowed login again on another web browser until the GUI has timed out.




Figure 3.2-2 Home button lists all function

3.3 System Monitoring



System monitoring provides administrators with information regarding NAS system resources. Admin can also check the system event log, allowing the administrator to be updated with the latest state of the system, and this information can be a basis for adjusting system configurations.

3.3.1 System Information

The System Information provides administrators with information regarding NAS model, network status, hardware status, and service status, as shown in Figure 3.3.1-1.




Figure 3.3.1-1 System Information

3.3.2 Resource Monitor

As shown in Figure 3.3.2-1, the Resource Monitor provides graphical information of usage of system resources, such as CPU, memory, and LAN ports. The statistics or usage of various resources are displayed, and updated (refreshed) periodically.

Statistics of System Resources:




Figure 3.3.2-1 Resource Monitor

The chart can be shown by RealTime, Day, Week, Month or Year view. (See Figure 3.3.2-1)

3.3.3 System Log

Administrators can view the records of system events in the System Log. Refer to Figure 3.3.3-1. All logs can be filtered by Date, Type and Level.

Type : Event type can be filtered, such as All, System, Storage, Service, Account, Backup, Schedule, and PlugIn.

Level: Level can be filtered such as all, ERROR, WARNING, and INFO.

Download Log: Administrators can save the NAS logs to a local computer. Click “Download log” and the NAS system will save the system log to the computer where NAS webpage was opened. The NAS system log is useful in analyzing NAS systems problems. Administrators can download the system log first and then analyze the logs. The saved log default filename is “NASlog.tgz”.

This function is very useful for system trouble shooting.

Clear All Log: Administrator can clear all logs with this button, but it is not recommended.

System Log						
Start Date:	2013-04-30	End Date:	2013-04-30	Type:	All	Level: All Query
Date/ Time	Type	Level	Client ID	Client IP	Message	
2013-04-30 19:07:57	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 19:06:47	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 18:56:41	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 18:49:14	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 18:41:57	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 18:08:59	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 17:53:59	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 17:30:32	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 17:12:19	System	INFO	admin	192.168.100.233	admin success to login	
2013-04-30 17:07:27	Storage	INFO	root	127.0.0.1	Detect FC Target : 2->50:01:43:80:24:23:68:12	
2013-04-30 17:07:06	Storage	INFO	root	127.0.0.1	Detect FC Target : 1->50:01:43:80:24:23:68:10	
2013-04-30 17:07:01	System	INFO	root	127.0.0.1	set IP 192.168.100.121 to system	
2013-04-30 17:07:00	System	INFO	root	127.0.0.1	NAS Boot	
2013-04-30 17:07:00	System	ERROR	root	127.0.0.1	Can not detect RAID Controller. Suggest to do Power off then Power on.	
2013-04-30 17:06:59	Storage	INFO	root	127.0.0.1	Init DB config	

Figure 3.3.3-1 System Log

3.4 System Manager



The System Manager enables NAS administrators to configure system setup such as Date/Time settings, Network settings, UPS settings, Event settings, Power settings, and Schedule Manager, and upgrade the NAS firmware version.

3.4.1 General

In General setting, admin can set or modify the "GUI" and "Date/Time" settings and other related options.

Host Name: Admin can set the NAS Host Name, which can be up to 16 characters and can only contain letters, numbers, hyphen (-) and underscore (_). A space or a period (.) cannot be used. Host name containing numbers only is also not allowed; it must contain at least one non-numeric character. See Figure 3.4.1-1.

Figure 3.4.1-1 General Setting

Protocol: Default web GUI protocol is set to "Both (HTTP/HTTPS)". There are three possible options: "HTTP", "HTTPS", and "Both (HTTP/HTTPS)".

Port: Default port is set to 80. If changed to another port number, option range is from 1 to 65536.

Timeout (min): Default is 5 minutes, which means admin will be automatically logged out from GUI if there is no activity (idle) in the GUI for 5 minutes. There are four options: 5, 15, 30, and Never. "Never" means no GUI timeout.





NOTE: Don't forget to logout GUI if Timeout is set to "Never", else you cannot login the GUI again from other web browser or PC.

Date/Time

Set up the NAS time and time zone here. See Figures 3.4.1-2 and 3.4.1-3.

Figure 3.4.1-2 General Date/Time setting

To change the date, click the calendar icon  and select the preferred date.

To change the time, click arrow-down button  in Time option, and select the preferred time.



To set the time zone, click the arrow-down  button in Time Zone option, and select the preferred time zone.

Figure 3.4.1-3 General Date/Time Setting

NTP Server: To enable the NAS to synchronize time from an NTP server, select the NTP Server box (check mark  will appear) and then enter the NTP server's IP address or fully qualified domain name. See Figure 3.4.1-2. (After NTP Server setting is done, system will sync time from NTP server every 24 hours.)


Sync Local Time to NAS: If you want to synchronize the NAS system time from local time of PC (which you used to login the NAS management GUI), click the "Sync local time to NAS" button.

Apply: After modifying settings, click "Apply" to save changes.

3.4.2 Network

Network management provides options to configure settings such as Adapter, DNS, IPv6, Security, and Routing Table.

Adapter:




Network									
Adapter DNS IPv6 Security Routing Table									
Edit Trunking Default Gateway: LAN_0									
Enable	Interface	Status	IP	Subnet Mask	Gateway	MTU	Speed/Mode	MAC	DHCP
<input checked="" type="checkbox"/>	LAN_0		192.168.100.121	255.255.255.0	192.168.100.121	1500	1000 Mb/s	00:e0:81:df:0c:c2	
<input type="checkbox"/>	LAN_1					1500	0 Mb/s	00:e0:81:df:0c:c3	

Figure 3.4.2-1 Network Setting

Changing Adapter settings:

Edit:

Select interface on the list (Figure 3.4.2-1), for example 'LAN_0' and then click the 'Edit' button. The following screen will be shown (Figure 3.4.2-2).



Edit Network

Interface:

DHCP: ☐

IP:

Subnetmask:

Gateway:

MTU:

OK Cancel

Figure 3.4.2-2 Edit Network Setting

Interface: The LAN Port name. (This name is fixed and can't be modified.)

DHCP: Click the DHCP box to enable DHCP client option (default is disabled). NAS will get a DHCP assigned IP address from a DHCP server, if DHCP server is available.

IP: To use static IP address (DHCP option is not checked), enter the preferred IP address, for example 192.168.1.1. In 'Subnetmask', enter a valid subnet mask, such as 255.255.255.0. In 'Gateway', enter a valid gateway IP address, for example 192.168.1.254.


(Default IP Address / Subnetmask / Gateway are: 172.16.0.1 / 255.255.255.0 / 172.16.0.1)

MTU: Set the Maximum Transmission Unit size of the network packets, in bytes.
(Default is 1500)

Trunking:

Trunking enables multiple network interfaces to be combined to form a single channel.


To setup Trunking, click 'Trunking' button, and the following screen will be shown.



The image shows a 'Trunk Setting' dialog box with the following fields and values:

- Interface: lan0, lan1 (dropdown menu)
- Mode: Balance-rr (dropdown menu)
- DHCP: ☐ (checkbox)
- IP: 192.168.1.1 (text field)
- Subnetmask: 255.255.255.0 (text field)
- Gateway: 192.168.1.254 (text field)
- MTU: 1500 (spin box)
- Buttons: OK, Cancel

Figure 3.4.2-3 Edit Trunk Setting

Interface: Click the arrow-down button  on the right, and then select which LAN ports will be included in Trunking mode. (This is multiple-choice.) After Trunk Setting setup is done, click "**OK**".

Mode: Please refer to the following list for options and description of each option.

Mode	Description	Switch Required
Balance-rr (Round-Robin)	Round-Robin mode is good for general purpose load balancing between two Ethernet interfaces. This mode transmits packets in sequential order from the first available slave through the last. Balance-rr provides load balancing and fault tolerance.	Supports static trunking. Make sure static trunking is enabled on the switch.
Active Backup	Active Backup uses only one Ethernet interface. It switches to the second Ethernet interface if the first Ethernet interface does not work properly. Only one interface in the bond is active. The bond's MAC address is only visible externally on one port (network adapter) to avoid confusing the switch. Active Backup mode provides fault tolerance.	General switches


Balance XOR	Balance XOR balances traffic by splitting up outgoing packets between the Ethernet interfaces, using the same one for each specific destination when possible. It transmits based on the selected transmit hash policy. The default policy is a simple slave count operating on Layer 2 where the source MAC address is coupled with destination MAC address. Alternate transmit policies may be selected via the <code>xmit_hash_policy</code> option. Balance XOR mode provides load balancing and fault tolerance.	Supports static trunking. Make sure static trunking is enabled on the switch.
Broadcast	Broadcast sends traffic on both network interfaces. This mode provides fault tolerance.	Supports static trunking. Make sure static trunking is enabled on the switch.
IEEE 802.3ad (Dynamic Link Aggregation)	Dynamic Link Aggregation uses a complex algorithm to aggregate adapters by speed and duplex settings. It utilizes all slaves in the active aggregator according to the 802.3ad specification. Dynamic Link Aggregation mode provides load balancing and fault tolerance but requires a switch that supports IEEE 802.3ad with LACP mode properly configured.	Supports 802.3ad LACP
Balance-tlb (Adaptive Transmit Load Balancing)	Balance-tlb uses channel bonding that does not require any special switch. The outgoing traffic is distributed according to the current load on each Ethernet interface (computed relative to the speed). Incoming traffic is received by the current Ethernet interface. If the receiving Ethernet interface fails, the other slave takes over the MAC address of the failed receiving slave. Balance-tlb mode provides load balancing and fault tolerance.	General switches
Balance-alb (Adaptive Load Balancing)	Balance-alb is similar to balance-tlb but also attempts to redistribute incoming (receive load balancing) for IPV4 traffic. This setup does not require any special switch support or configuration. The receive load balancing is achieved by ARP negotiation sent by the local	General switches

	system on their way out and overwrites the source hardware address with the unique hardware address of one of the Ethernet interfaces in the bond such that different peers use different hardware address for the server. This mode provides load balancing and fault tolerance.	
--	---	--

Default Gateway:



Figure 3.4.2-4 Set Default Gateway to a Network Interface

In the Adapter list in Figure 3.4.2-1, to set Default Gateway, click the arrow-down button  on the right (Figure 3.4.2-4), and select the interface that will be assigned as default gateway. The NAS system supports only single default gateway interface. The default setting is LAN_0.

DNS:

As shown in Figure 3.4.2-5, NAS system supports up to two DNS server IP address.

To setup DNS server, enter the DNS server IP address in 'DNS Server 1'. If another DNS server will be setup, enter the other DNS server IP address in 'DNS Server 2'.

Apply: After modifying settings, click "Apply" to save changes.



Figure 3.4.2-5 Edit DNS Setting

Hosts Table:

Click "Hosts Table" (see Figure 3.4.2-5) to edit the Hosts Table. The Hosts Table contains mapping of IP addresses to hostnames. (See Figure 3.4.2-6.)



Figure 3.4.2-6 Edit Hosts Table

The Hosts Table can be modified to add IP address and hostname mapping. After editing Hosts Table, click 'OK'.

LmHosts Table:

Click "LmHost Table" (see Figure 3.4.2-5) to edit the LmHosts Table. The LmHosts Table is a mapping of IP addresses to Samba NetBIOS names. It is similar to the Hosts Table, except that the hostname component must correspond to the NetBIOS naming format. (This is optional.)

The LmHosts Table can be modified and add IP address and NetBIOS hostname mapping. After editing LmHost Table, click 'OK'. (See Figure 3.4.2-7.)

OK: After modifying settings, click "OK" to save changes.

Cancel: Click this to undo any changes.




Figure 3.4.2-7 Edit LmHosts Table

IPv6:

By default, IPv6 is set to Disabled, as shown in Figure 3.4.2-8. IPv6 can be enabled by selecting "Enabled". The default IPv6 IP will be displayed in the list after being enabled, as shown in Figure 3.4.2-9.




Figure 3.4.2-8 IPv6 Disabled by default




Figure 3.4.2-9 IPv6 Table after Set to Enabled

Edit:

Select an interface on the list, for example LAN_0, and then click the 'Edit' button. A screen like below will be displayed, and the IPv6 settings can be configured.



Figure 3.4.2-10 Edit IPv6 Setting

Interface: The LAN Port name. (This name is fixed and cannot be modified.)

IPv6: Enter the IPv6 address which is usually a 128-bit address, divided into eight groups separated by colon ":", and each address is a hexadecimal digit representing 4-bits.

For example: 2001:0db8:85a3:08d3:1319:8a2e:0370:7344

Other IPv6 formats that can be used are shortened format such as omitting leading zeros or using double colon.

Prefix: Select the prefix.

Gateway: Input IPv6 Default Gateway.

Security:

The Security setting determines which client IP address or range of IP addresses are allowed or rejected access to the NAS resources.



Figure 3.4.2-11 Security Table

Add: Click 'Add' to add a security setting. The screen below will be displayed.



Figure 3.4.2-12 Add Security Table

Type: There are 2 options: Single (for single IP address) or Range (for a range of IP addresses)

Priority ID: This setting allows the NAS system to make a judgment according to the level of Priority ID, with 1 as the highest priority. For example: If an IP address 192.168.1.10 is included in the Range type (192.168.1.1 – 192.168.1.20) and the Priority ID is set to 1 and Policy is ACCEPT (allow access), and the same IP address 192.168.1.10 is set as Single type with Priority ID 2 and Policy is DROP, the higher priority ID 1 will be the effective one, hence the IP address 192.168.1.10 will be allowed access.

Policy: There are 2 options: ACCEPT (allow the IP or range of IP) or DROP (reject the IP or range of IP)

IP: When the Type option is set as Single, enter a single IP address.

When the Type option is set as Range, enter the starting IP address and ending IP address for the range of IP addresses.

Routing Table:

Routing Table allows you to setup static routes to specific hosts or networks.



Destination	Subnetmask	Gateway	Interface	
0.0.0.0	0.0.0.0	10.10.20.2	bond0	
10.10.20.0	255.255.255.0	0.0.0.0	bond0	

Figure 3.4.2-13 Routing Table

Add: Click 'Add'. The Add Route window will appear.




Figure 3.4.2-14 Edit Routing Table

Destination: Please enter the IP address or network range. For example:
192.168.0.1 or 192.168.0.

Netmask: Input a netmask, for example: 255.255.255.0

Type: If "gw" is selected, NAS will use the Gateway for routing packets. If "dev" is selected, NAS will use a LAN interface for routing packets.

Gateway: If "gw" is selected, please enter the gateway IP address. If "dev" is selected, please select a LAN interface.

OK: After modifying settings, click "OK" to save changes.

Cancel: To undo any changes, click "Cancel".

3.4.3 UPS

The NAS system supports UPS (uninterruptible power supply) equipment.
(see Figure 3.4.2-5)

Figure 3.4.3-1 UPS Configuration

Enable: Select (check) this to enable support for UPS.

Service: UPS

UPS Vendor: (For example: APC)

Interface: There are three options for interface connection: COM1, USB, and SNMP.

Cable model: Please select the terminal type.

Interface	Cable model
COM1	simple/smart/ether
USB	usb
SNMP	ether

Shutdown Delay (min): Use this to set the delay time in minutes. After a power failure, UPS will shutdown the NAS when the Shutdown Delay time has expired.

SNMP IP: The IP address of APC UPS. This is enabled only when Cable model is set to SNMP.

Apply: After modifying settings, click "Apply" to save changes.

3.4.4 Event

Email setting:

Enable Email notification for sending message when a system failure event occurs.

The screenshot shows the 'Event' configuration window with the 'Email Setting' tab selected. The fields are as follows:

- SMTP server:** 192.168.10.253
- Sender:** admin@mail.com
- Port:** 25 (with up/down arrows)
- SMTP Authentication:** ☐
- Account:** (empty text box)
- Password:** (empty text box)
- Protocol Type:** ☐ Use SSL/ TLS secure connection; SSL (selected in dropdown)
- Recipient:** x@x.com.tw

Below the Recipient field, a note states: 'Note : Separated by a semicolon if multiple Email Recipient'. At the bottom, there are two buttons: 'Apply and Send a test email' and 'Apply'.

Figure 3.4.4-1 Event Setting

SMTP server: Input the SMTP server's IP address.

Sender: Input the sender's email address.

Port: Enter the port number used by SMTP server. Default port is 25.

SMTP Authentication: If the SMTP server requires authentication using username and password, please select (enable) it.

Account: Enter a valid SMTP account name.

Password: Enter the password of SMTP account name.

Protocol Type: If SMTP server supports SSL/TLS secure connection, please select (enable) it.

Recipient: Please enter the email address of the first email recipient. If there are more than one recipient, please separate them with a semicolon. For example: admin@nas.com; tony@nas.com

Apply and Send a test mail: Use this to save changes, and at the same time send a test email to the recipient(s).

Apply: Click to save changes.

SNMP Trap Receiver :

This setting provides SNMP trap notification by sending message when system failure event occurs.

The screenshot shows a web interface titled "Event". It has three tabs: "Email Setting", "SNMP Trap Receiver", and "Event Option". The "SNMP Trap Receiver" tab is selected. Below the tabs, there is a text input field labeled "Trap Receiver IP:". At the bottom of the form, there are two buttons: "Apply and Send a test snmp trap" and "Apply".

Figure 3.4.4-2 SNMP Trap Setting

Trap Receiver IP: Input here the IP address of SNMP Trap Receiver, i.e. computer running SNMP application that will receive the event messages.

Apply and Send a test snmp trap: Use this to save changes, and at the same time send a test snmp trap to the Trap Receiver.

Apply: Click 'Apply' to save changes.

Event Option: This setting allows you to select which system failure events will be included when messages or event notifications are sent.




Figure 3.4.4-3 Event Options

Apply: Use 'Apply' button to save changes.



NOTE: The events selected in the Event Option will apply to both Email notification and SNMP Trap notification.

3.4.5 Power

Power provides option to Reboot or Shutdown the NAS system, or to reset the NAS system to factory default by deleting configuration and/or data.

Figure 3.4.5-1 Power Setting

NAS Reboot: Select 'Reboot Confirm' and click 'Reboot' button to reboot the NAS system.

NAS Shutdown: Select 'Shutdown Confirm' and click 'Shutdown' button to shutdown system.

NAS to Factory Default: To reset the NAS system to factory default settings, enter the text "ResetToDefault" in the 'Confirm Text:' box, and then click 'Reset to Factory Default' button.

Description of Options in Resetting to Factory Default:

Delete All: Delete all data, NAS config, and Array.

Keep Raid, Delete Data and Config: Delete NAS configuration and data, but the Array will be retained.

Keep Raid and Data, Delete Config: Delete NAS configuration, but the Array and data will be retained. Only the NAS system settings will be cleared and reverted to the default value. Array information and data will be retained.

The "Reboot" can also be defined with scheduled job in Schedule manager. (See Chap 3.4.8)

3.4.6 Upgrade

This page allows updating the NAS firmware version.




Figure 3.4.6-1 Upgrade

Click the '**Browse...**' button and select the firmware file, and then click '**Upgrade**'. The firmware file will be automatically uploaded and updated to the NAS system, after which the NAS system will reboot.



NOTE:

- A. When NAS is updating, do not power off the NAS to avoid system update failure.
- B. When NAS is updating, make sure that the client computers accessing the NAS data (such as share folders) have been disconnected to avoid damaging the data, because during firmware upgrade the NAS system will be rebooted automatically.
- C. After upgrade and before re-login GUI, it is better to clear the web browser cache.

3.4.7 Tools

Tools provide the administrator with some useful functions. Select the function and then click 'Query'.

Tools options	Description
Connections	Shows current Samba (Windows Client), NFS, AFP (Mac Client), SSH, Telnet, and FTP client connections list.
ps	Shows the list of NAS system processes that are currently running.
df	Shows the usage information, such as used capacity or free space, of mounted volumes or partitions in the NAS system.
top	Shows the NAS system CPU and memory usage and program status.
ping	Can be used to test network connectivity. Enter the IP address to test network connection.
dmesg	Shows the kernel messages of NAS system boot-up process.
iostat	Shows the current disk device loading information or statistics.
netstat	Shows various information about the NAS system network connection.
syslog	Shows the latest system message log generated by kernel.

Tools					
Connections ps df top ping dmesg iostat netstat sysLog					
Query					
Result					
Active Internet connections (servers and established)					
Proto	Recv-Q	Send-Q	Local Address	Foreign Address	State
tcp	0	0	0.0.0.0:161	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:2049	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:548	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:37	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:9734	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:7	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:34313	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:3306	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:13	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:111	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:44112	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:22	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:23	0.0.0.0:*	LISTEN
tcp	0	0	127.0.0.1:4700	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:60253	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:44445	0.0.0.0:*	LISTEN
tcp	0	0	0.0.0.0:445	0.0.0.0:*	LISTEN
tcp	0	0	:::50887	:::*	LISTEN
tcp	0	0	:::111	:::*	LISTEN

Figure 3.4.7-1 Tools

3.4.8 Schedule Manager

This function allows administrators to control scheduled tasks in the NAS. There are 5 Types of functions that can be set with schedule: Data Backup, Data Copy, Snapshot, Rsync and Power (Restart/ON/OFF).




Figure 3.4.8-1 Schedule Manager

Add Schedule: Click '**Add**' button. The setup screen below will appear.




Figure 3.4.8-2 New Schedule Task

Type: This field has five options: Data Backup, Data Copy, Snapshot, Rsync and Power.

Plan Name: Select the name of the backup plan (available only in Data Backup, Data Copy, Snapshot, and Rsync).

Action: Select the type of action for the schedule, such as Power Restart, Power ON, or Power OFF (available only in Power).

Start Date: Select the date when to start backup. Please select current date or a future date.

Start Time: Select the time when to start backup. This field is a 24-hour clock.

Repeat:

Option	Description
Disabled	Disables the backup schedule. When you need to temporarily turn off this schedule, you can use this option to pause the backup schedule.
Once	This option will perform a one-time backup based on the set date and time. This option will change to Stop when this scheduled backup has run once.
Hourly	The hourly schedule will be based on the start date and time. Every hour, the scheduled backup will be executed.
Daily	The daily schedule will be based on the start date and time. The scheduled backup will be performed daily.
Weekly	The weekly schedule will be based on the start date and time. The scheduled backup will be executed weekly.
Every 2 weeks	Every two weeks schedule will be based on the start date and time. Scheduled backup will be performed once every two weeks.
Monthly	The monthly schedule will be based on the start date and time. Once a month, the scheduled backup will be performed.
Yearly	The annual schedule will be based on the start date and time. Every year, the scheduled backup will be executed.



NOTE:

- A. The same backup plan name cannot be selected to have different schedule settings.
- B. When setting backup schedule, the past date and time cannot be selected.
- C. Setting scheduled tasks with time too close to each other is not recommended.

Edit schedule: Select a schedule and click '**Edit**' to modify schedule, such as the Start Date, Start Time, and Repeat settings.

Delete a schedule: Click  at the right column of the plan to be deleted.

3.5 Storage Manager

This page allows administrators to do Array (RAID) configuration and disk allocation, and management of Volume Groups and Logical Volumes, iSCSI and FC volumes, and Share folders.

3.5.1 RAID / Array Manager

The screenshot shows the RAID / Array Manager interface. On the left is a sidebar with a tree view containing 'RAID', 'Array List', 'Array01', 'Spare List', and 'All Disk List'. The main area is divided into three sections: 'Array List', 'Spare List', and 'All Disk List'.

Array List

Name	Level	Size(GB)	stripe(KB)	Volume Group	Status	Use State
Array01	RAID 0	7995	64	VG01	normal	IN_USED

Spare List

Slot	Size(GB)	Status	Model	FW	Temperature(°C)	Reading Errc
------	----------	--------	-------	----	-----------------	--------------

All Disk List

Slot	Size(GB)	Status	Model	FW	Temperature(°C)	Reading Errc
1:1	0	-	-	-	0	0
1:2	3000	Array01	ST33000651AS	CC44	36	0
1:3	2000	Array01	Hitachi HDS722020ALA	JKAOA3M	34	0
1:4	0	-	-	-	0	0
1:5	0	-	-	-	0	0
1:6	2000	Array01	Hitachi HDS722020ALA	JKAOA3M	35	0
1:7	3000	Array01	ST33000651AS	CC44	34	0
1:8	0	-	-	-	0	0
1:9	0	-	-	-	0	0

Page 1 of 1 | Displaying 1 - 16 of 16

Figure 3.5.1-1 Array Manager

Functions on Array Manager (left pane):

Array List:

- Displays the list of existing Arrays, and the member hard disks in each Array
- After selecting the Array List option, on the right pane you can select an Array and do Add/Extend/Delete Array operation.

This is a close-up of the 'Array List' section. It shows a toolbar with 'Add', 'Extend', 'Migration', and 'Refresh' buttons. Below is a table with columns: Name, Level, Size(GB), stripe(KB), Volume Group, Status, and Use State. The table contains one entry: Array01, RAID 0, 7995, 64, VG01, normal, IN_USED. There are also small icons for configuration and deletion at the end of the row.

Name	Level	Size(GB)	stripe(KB)	Volume Group	Status	Use State
Array01	RAID 0	7995	64	VG01	normal	IN_USED

Figure 3.5.1-2 Array List

Add: Press 'Add' button. The Add Array window will appear.

Free Disk List				
<input checked="" type="checkbox"/>	Slot	Model	Size	FW
<input checked="" type="checkbox"/>	1:2	ST33000651AS	3000	CC44
<input checked="" type="checkbox"/>	1:3	Hitachi HDS722020ALA	2000	JKAQA3M
<input checked="" type="checkbox"/>	1:6	Hitachi HDS722020ALA	2000	JKAQA3M
<input checked="" type="checkbox"/>	1:7	ST33000651AS	3000	CC44

Page 1 of 1

OK Cancel

Figure 3.5.1-3 Add Array

Name: Displays the Array name. System will automatically generate an Array name and can't be modified.

Level: Select the RAID Level for the Array. The NAS supports RAID levels 0, 1, 3, 5, 6, 10, 50 and 60 (by selected model). The detailed information of each RAID level is described in the succeeding page.

Free Disk List: This is the list of unused hard disks. Administrator can select which hard disk to include in the Array.

Slot: Shows the Chassis ID: hard disk slot number

For example: 1:9 is the first chassis (usually the NAS chassis itself) and 9th slot hard disk

Model: The hard disk model

Size: The hard disk capacity; unit is gigabytes (GB).


FW: The hard disk firmware version.

Extend Array: Select the Array name then click 'Extend' button, and then choose an unused hard disk that will be used for Array expansion.



NOTE:

- If an Array is already in use (has been assigned to a volume group), this Array cannot be deleted.
- If initialization of new Array is completed, but new Array does not appear in the list, click 'Refresh' or 'Refresh' to update the Array List.

Delete Array: On the left pane, select 'Array List' under 'Array Manager' (RAID), then on the Array List on right pane click the delete icon  on the right side of the Array to be deleted.

Before deleting an Array, please make sure that the selected Array is not in use, such as Array is included in a volume group. If Array is included in a VG, delete first the VG. After VG is deleted, then the Array can be deleted.

If a VG contains existing logical volume(s) and share folder(s), delete first the share folder(s) and logical volume(s), and then delete the VG and the Array.




Figure 3.5.1-4 Array Manager (RAID)

After clicking the delete icon, a confirmation window will appear to confirm deletion of selected Array. Select the 'Confirm:' box and click the 'Yes' button to confirm the deletion of Array. System will delete the selected Array.



Figure 3.5.1-5 Confirm Message to Delete an Array




Spare List						
 Add  Refresh						
Slot	Size(GB)	Status	Model	FW	Temperature(°C)	Reading Error
1:11	999	Spare	SEAGATE ST31000424SS	0006	33	0

Figure 3.5.1-6 Spare List

Spare List: On the right pane, the Spare List (Figure 3.5.1-6) will show the list of Hot Spare hard disks. You can add an unused hard disk as Hot Spare.

Add Spare: Click 'Add', select a hard disk, and click 'OK' button. In Confirm window, select the 'Confirm:' box and click 'Yes'. The hard disk will be set as Hot Spare.

Delete Spare: To delete a Hot Spare hard disk and make it as unused hard disk, click the delete  icon on the right of the Hot Spare hard disk.

After that, the confirmation window will appear (Figure 3.5.1-7) . To confirm deletion of Hot Spare hard disk, check the 'Confirm:' box and click the 'Yes' button. The selected Hot Spare hard disk will become unused hard disk.




Figure 3.5.1-7 Confirm Message to Delete a Spare Disk

All Disk List: After selecting this option, a list of all hard disks and hard disk status will be shown on the right pane.

All Disk List						
Slot	Model	Size(GB)	FW	Usage	Temperature(°C)	Reading Error
0:1	-	0	-	-	0	0
0:2	WDC WD2003FYYS-02W0B	2000	01.01D0	Array01	42	0
0:3	WDC WD2003FYPS-02W3B	2000	04.01G0	Array01	36	0
0:4	WDC WD2003FYPS-02W3B	2000	04.01G0	Array02	36	0
0:5	-	0	-	-	0	0
0:6	-	0	-	-	0	0
0:7	-	0	-	-	0	0
0:8	-	0	-	-	0	0
0:9	-	0	-	-	0	0
0:10	-	0	-	-	0	0
0:11	-	0	-	-	0	0
0:12	-	0	-	-	0	0
0:13	WDC WD2003FYPS-01U1B	2000	04.05G0	Array02	43	0
0:14	HD57250SLA360	499	K2AOAB0	SPARE	41	0
0:15	-	0	-	-	0	0
0:16	-	0	-	-	0	0

Figure 3.5.1-8 All Disk List

3.5.2 Volume Group Manager

Volume Group (VG) is a storage pool for creating logical volumes. You need to create at least one VG (first VG is VG01) by adding an Array (for example Array01) to initialize the NAS system and enable NAS functions.




Figure 3.5.2-1 Volume Group Manager

Add: To add a Volume Group, click 'Add' button, and then select the Array name to be included in the VG and click 'OK' button. The NAS system will automatically create the new Volume Group.




Figure 3.5.2-2 Create a new Volume Group

Insert Array: To expand the size of a Volume Group, select the Volume Group name and click 'Insert RAID' button. Select the Array name that will be joined to the VG, and then click 'OK'. In Confirm window, select the 'Confirm:' option and click 'Yes'. The NAS system will automatically expand the size of the selected VG using the added Array.

Remove Array: To remove an Array from a Volume Group, select the Volume Group name and click 'Remove RAID', and then click 'OK' button. In Confirm window, select the 'Confirm:' option and click 'Yes'. The NAS system will automatically remove the selected Array from the VG, and the VG size will be reduced accordingly.




Figure 3.5.2-3 Remove Array

Add: To create a Logical Volume (LV) from a Volume Group

- Select first the Volume Group name (VGXX) where a Logical Volume will be created, and then click the 'Add' button under Logical Volume List.





Figure 3.5.2-4 Volume Group Status

- b. The 'Add Logical Volume' window will appear. Enter the logical volume name, change the Volume Group Name where the LV will be created if necessary, select the file system format for the LV, and set the LV size. Click 'OK' when done.

Figure 3.5.2-5 Creating a Fixed Size Logical Volume

Name: The NAS system will automatically generate a default LV name 'LV_x' where x is a number in series starting from 1, such as LV_1. The LV name can also be modified if needed.

Volume Group Name: Click the arrow-down  button on the right, and a drop-down menu will appear where a volume group name can be selected.

Free Size(GB): This displays the selected volume group's unused capacity.

File System: Select the file system format for the LV, default is **ext4**. Format options are described below.

Format	Description
ext3	This file format is suitable for small I/O, average single-file size of about 4KB-50MB.
ext4	This file format is suitable for big I/O, average single-file size of about 4KB-128MB
xfs	This file format is suitable for big I/O, average single-file size of about 128MB-1GB or above
zfs	This file format is suitable for big I/O, average single-file size of about

	128MB-1GB or above, also support compression de-duplication and SSD caching
--	---



NOTE: The LV Name only allows up to 32 characters, and can only contain letters, numbers, hyphen (-) and underscore (_).

Size(GB): The size of Logical Volume to be created must be based on the “Free Size (GB)” field, size must be less than the Volume Group available capacity.

Volume Allocation options:

Fixed Size: Create a logical volume with fixed physical size.

Thin Provision: Create a Thin Provisioning pool with Size, and create a Thin Provisioning volume with Allocation Size (option below).

Allocation Size(GB): This field is enabled only when creating LV with Thin Provision. The minimum size of a Thin Provisioning volume is 50GB, and the maximum size is 32TB or 4 times of physical volume size.

The screenshot shows a window titled "Add Logical Volume" with the following fields and values:

- Name: LV_3
- Volume Group: VG01
- File System: ext4
- Free Size(GB): 1614
- Size(GB): 100
- Volume Allocation: ☒ Thin Provision
- Allocation Size(GB): 400

A warning message at the bottom reads: "Thin Provision volume size must be at least 50 GB." The dialog has "OK" and "Cancel" buttons at the bottom right.

Figure 3.5.2-6 Create a Thin Provisioning Logical Volume




Figure 3.5.2-7 Create a ZFS Logical Volume

Compression: This allows tradeoffs between the amount of CPU required for compression and the resulting compression efficiency. Compression also provides increased throughput and performance within the system due to the fact that less data is being written to and read from disk, resulting in fewer I/O operations.

De-duplication: If a file system has the dedup property enabled, duplicate data blocks are removed as they are written to disk. The result is that only unique data is stored on disk and common components are shared between files.

Expanding Logical Volume Capacity:

Select a Logical Volume that need to be expanded in the Logical Volumes List (See Figure 3.5.2-4) and click '**Edit**', change the "Logical Volume Size (GB)" to the preferred size, and then click 'Apply'. In Confirm window, select the "**Confirm:**" option and click '**Yes**'. The Logical Volume size will be expanded automatically.

If the volume set as a Thin Provision Volume, you can also modify the field "Thin Provision Size" here (See Figure 3.5.2-8).

LV_3

Logical Volume Name : LV_3 Mount Point: /vol/LV_3
 Logical Volume Size(GB): 100 File System: ext4
 Volume Group Free Size(GB): 1514 Volume Group: VG01
 Volume Allocation: Thin Provision Create Time: 2013-05-07 19:12:48
 Thin Provision Size(GB): 400

Apply

Logical Volume Usage

Name	Size(GB)	Used Size(GB)	Logical Volume	Owner	Owner Group
share03	100	0	LV_3	admin	admins

Free: 100 GB

Figure 3.5.2-8 Logical Volume Information

**NOTE:**

1. The logical volume size can only be expanded, but cannot be reduced.
2. It might take time to expand a volume with file system.

Volume Encryption:

In each logical volume information, if share folders have not been created yet in the logical volume, as shown in Figure 3.5.2-9, the volume can be encrypted by clicking "**Encrypt**" and then typing the password. After an encrypted volume is created, system will download the key file automatically. Please keep the key file safely. The volume data will become invalid without key file.

', and three buttons: 'Encrypt', 'Mount', and 'Unmount'."/>

Volume Group

Volume Group: VG01
 HOME
 LV_1
 LV_2
 LV_3
 LV_4
 VG02

LV_4

Logical Volume Name : LV_4 Mount Point: /vol/LV_4
 Logical Volume Size(GB): 10 File System: ext4
 Volume Group Free Size(GB): 1504 Volume Group: VG01
 Volume Allocation: Fixed Size Create Time: 2013-05-07 19:16:44

Apply

Logical Volume Encryption

Status: Unencrypted
 Automatic Mount After Boot: ☐

Encrypt Mount Unmount

Figure 3.5.2-9 Creating an Encrypted Logical Volume





Figure 3.5.2-10 Set Password for the Encrypted Logical Volume

The volume will not be mounted automatically after encryption. You can mount the encrypted volume manually by clicking "**Mount**" (Figure 3.5.2-11) and input the password. Then the encrypted volume will be mounted  and ready to use (Figure 3.5.2-12).




Figure 3.5.2-11 Encrypted Logical Volume in Un-mounted State

Automatic Mount After Boot:

Default is enabled. The volume will be automatically mounted after boot without typing the password. If disabled, you have to manually mount the volume and type password after every boot.




Figure 3.5.2-12 Encrypted Logical Volume in Mounted State

SSD cache: (support by zfs)

Frequently accessed data is stored in RAM, and less frequently accessed data can be stored on slower media, such as SSD disks. Data that is not often accessed is not cached and left on the slow hard drives. If old data is suddenly read a lot, NAS will automatically move it to SSD disks or to RAM.




Figure 3.5.2-13 Enable SSD Caching


Setting SSD

Name: VG01

Enabled SSD Cache: ☒

Used SSD List

Add SSD

SSD Name	Device Nam	Model	Size	FW	
ssd1	sdb	INTEL SSD5C2BW240...	240	DC32	

OK

Cancel

3.5.3 iSCSI Manager

The iSCSI Manager allows administrator of the NAS system to setup logical volumes as iSCSI Target Volumes. A logical volume that is not yet formatted or has no existing share folder in it can be setup as an iSCSI volume device.




Figure 3.5.3-1 The iSCSI Manager

Add iSCSI Target: To add an iSCSI target, click 'Add' icon in the iSCSI Target List shown in Figure 3.5.3-1. The iSCSI Target setup will appear (Figure 3.5.3-2).




Figure 3.5.3-2 Create iSCSI Target

Name: Input iSCSI Target name

CHAP: If CHAP authentication is needed, select the 'CHAP:' option to enable it, and then input the CHAP Login ID and CHAP Password.

InitialR2T: Initial Ready to Transfer. Default is disabled. If needed to enable this option, please select it.

I.M.D.: Immediate Data. Default is disabled. If needed to enable this option, please select it.

MaxRecv(KB): Maximum data per PDU (Protocol Data Unit) to receive. Default value is 4096 KB. If needed to change the value, please modify it.

MaxXmit(KB): Maximum data per PDU (Protocol Data Unit) to transmit. Default value is 4096 KB. If needed to change the value, please modify it.

Max Connection: Default value is 1. If needed to increase the maximum number of initiator connections, please modify the value.

For example: If four initiator connections are allowed on the iSCSI target, set the 'Max Connection' value to 4.

Interface: Specify the network port dedicated for iSCSI connection. iSCSI initiators can only connect to the iSCSI target via this port.



NOTE:

The Name only allows up to 32 characters, and can only contain letters, numbers, hyphen (-) and underscore (_).

Delete iSCSI Target: To delete an iSCSI Target, select the 'Remove' icon on the right side of the iSCSI target name to be deleted. The Confirmation window will appear. Select the "Confirm:" option and click 'Yes'. The iSCSI Target will be deleted.




Figure 3.5.3-3 Confirm Message to Delete iSCSI Target

Add iSCSI Target Volume: Click 'Add' icon on the iSCSI Volume List. The Add iSCSI Volume window will appear.

Select a Target name, and choose the logical volume to be used as iSCSI volume, set the Size(GB), and select the Block Size(KB). After completing the setup, click 'OK'. The new iSCSI Target Volume will be created.





Figure 3.5.3-4 Assign a Volume to the iSCSI Target

Block Size: The default setting is 512. There are four options: 512, 1024, 2048, and 4096



NOTE: The Thin Provision volume does not support Windows full format; user can only use the quick format.

Delete iSCSI Target Volume: Click the 'Remove iSCSI Logic Volume' icon  on the right of the iSCSI target volume to be deleted. The confirmation window will appear. Check the "Confirm:" option and click 'Yes'. The iSCSI Target Volume will be deleted.

Add Initiator: Click the 'Add' icon under the Initiator List. The Add Initiator window will appear. Select a Target name, enter the Initiator iqn name, and set the Permission. Click 'OK' when done.




Figure 3.5.3-5 Add Initiator



NOTE: The Initiator Name only allows up to 64 characters, and can only contain letters, numbers, hyphen (-) and underscore (_).

Initiator List			
Add Edit Refresh			
Target	Initiator	Permission	
iqn.2013-05.com.nas:naslv5	iqn.2013-05.com.micorsoft:inittator1		

Figure 3.5.3-6 Initiator List

Edit Initiator: To edit the Initiator permission, select from the Initiator List the Initiator name and click "Edit", or double click the Initiator name or its Permission. The following screen will appear. Only the Permission setting can be modified.





Figure 3.5.3-7 Edit Initiator Permission

Permission: Default is read/write. There are two options available: "R/W" (read/write) and "Read Only".

After modification is completed, click 'OK' button to apply the setting. If you want to undo changes, click the 'Cancel' button.

Remove Initiator: In the Initiator List, click the 'Remove' icon  on the right side of the Initiator name. The Confirm window will appear. Select the "Confirm:" option and click 'Yes'. The Initiator name will be deleted.




Figure 3.5.3-8 Confirm Message to Delete an Initiator

3.5.4 FC Manager

The FC Manager allows administrator of the NAS system to setup logical volumes as Target Volumes for use in Fibre SAN environment, allowing administrators to directly integrate with existing Fibre SAN environment and enable direct access to the NAS data.




Figure 3.5.4-1 FC List

Enable or Disable FC Target Port:

Default setting of FC Target Port is Active. If needed to disable an FC Target Port, select the FC Target Name from the FC Target List and click 'Edit'. The Edit FC Target window will appear. Select the Stop option and click 'OK'. The selected FC Target Port will be disabled.





Figure 3.5.4-2 Active FC Target

Add FC Volume:

Click **'Add'** in the Logic Volume List. The Add FC Volume window will appear (Figure 3.5.4-3). Select the corresponding FC Target WWN, select a logical volume and choose the Block Size. When done, click **'OK'**. The settings will be immediately applied. When setup is complete, the FC Volume can be accessed via the FC Target Port, which can be connected directly to a server's FC HBA or to an FC SAN Switch.



The 'Add FC Volume' dialog box contains the following fields and controls:

- Target:** A dropdown menu showing the value '50:01:43:80:24:23:67:48'.
- Logical Volume:** A dropdown menu showing the value 'LV01'.
- Size(GB):** A text input field containing the value '100'.
- Block Size:** A dropdown menu showing the value '512'.
- At the bottom right, there are two buttons: **OK** and **Cancel**.

Figure 3.5.4-3 Add FC Volume

Block Size:

The default setting is 512. There are four options: 512, 1024, 2048, and 4096




NOTE: The Thin Provisioning volume does not support Windows full format; user can only use the quick format.

Add FC WWN Initiator:

This function allows admin to assign WWN initiator and permission. Click **'Add'** in the WWN List. The Add WWN window will appear. Input the WWN initiator in the field.

Permission:

Default is read/write. There are two options available: "R/W" (read/write) and "Read Only".




The 'Add FC WWN Initiator' dialog box contains the following fields and controls:

- Target:** A dropdown menu showing the value '50:01:43:80:24:23:67:48'.
- WWN:** An empty text input field.
- Permission:** Two radio button options: **R/W** (selected) and **Read Only**.
- At the bottom right, there are two buttons: **OK** and **Cancel**.


Figure 3.5.4-4 Add FC WWN Initiator

When done, click '**OK**' button to apply the setting. To undo changes, click the '**Cancel**' button.

Remove WWN Initiator:

In the WWN List, click the 'Remove' icon  on the right side of the WWN initiator name. The Confirm window will appear. Select the "Confirm:" option and click 'Yes'. The WWN initiator name will be deleted.

Remove FC Target Volume:

Click the FC Target and find the volume in the Logical Volume List. Click the remove icon  on the right side of the Logical Volume List (Figure 3.5.4-5). The confirmation window will appear. Check the "**Confirm**" option and click '**Yes**'. The FC Volume will be removed from the target.





Figure 3.5.4-5 FC Target Volume Information

3.5.5 Share Manager

Share Manager allows admin to manage share folders that can be accessed by users via Samba (SMB/CIFS), NFS, AFP, FTP, WebDAV, and Rsync.




The screenshot shows the 'Share' window with a 'Share List' sidebar and a main table. The table lists four shares: 'home', 'share01', 'share02', and 'share03'. Each row includes columns for Name, Size(GB), Usage(GB), Logical Volume, Owner, Owner Group, Window, Linux, and MAC. The 'home' share has a size of 2GB and usage of 0GB, with logical volume HOME. 'share01' and 'share02' have a size of 100GB and usage of 0GB, with logical volumes LV_1 and LV_2 respectively. 'share03' has a size of 100GB and usage of 6.4GB, with logical volume LV_3. All shares are owned by 'admin' and belong to the 'admins' group. The 'Window' column has green checkmarks for all shares. The 'Linux' and 'MAC' columns have red minus signs for all shares. There are red trash icons at the end of each row.

Name	Size(GB)	Usage(GB)	Logical Volume	Owner	Owner Group	Window	Linux	MAC
home	2	0	HOME	admin	admins	✓	✗	✗
share01	100	0	LV_1	admin	admins	✓	✗	✗
share02	100	0	LV_2	admin	admins	✓	✗	✗
share03	100	6.4	LV_3	admin	admins	✓	✗	✗

Figure 3.5.5-1 Share List

Add Share: In the Share List, click 'Add'. The Add Share window will appear. Follow the setup instructions step by step. After setup in one page, click 'Next' to go to next setup page until completed and share folder is created.



The screenshot shows the 'Add Share' window with a sidebar containing 'Setting', 'Access Right', and 'Conclusion'. The 'Setting' tab is selected. The 'Setting' section contains the following fields:

- Name: share04
- Owner: admin
- Owner Group: admins
- Volume Group: VG01
- Logical Volume: LV_1
- Permission: ACL

The 'Share Protocol' section contains the following checkboxes:

- Window: ☒
- Linux: ☐
- MAC: ☐

At the bottom of the window are buttons for 'Previous', 'Next', and 'Cancel'.

Figure 3.5.5-2 Create a New Share

Name: Enter name of the share folder. The Name can be up to 32 characters, and can only contain letters, numbers, hyphen (-) or underscore (_).

Owner: Default share folder owner is admin. If needed to change the owner, select other user account.

Volume Group: Select the volume group where the share folder will be created.

Logical Volume: Select the logical volume where the share folder will be created, or create a new logical volume by selecting "Create New".

New Share Size (GB): This option appears only when "Create New" is selected in Logical Volume. Enter the size for the new volume to be created.

Volume Group Free size (GB): This option appears only when "Create New" is selected in Logical Volume. This is the available capacity of the selected Volume Group. This information is for reference only and cannot be modified.

Permission: Default is ACL. There are three options available: ACL, No ACL, and Public.

Share Protocol: Default option selected is Windows. There are three options available: Windows (Samba), Linux (NFS), and MAC (AFP).

When setup is completed, click '**Next**' to go to the Access Right configuration page. See Figure 3.5.5-3.




Figure 3.5.5-3 Set Access Right for the New Share

Add Account Permission:

In Access Right page, click **'Account'** button. The Account List window (Figure 3.5.5-5) will appear. Select the name of the account that will be assigned access permission to the share folder and click **'OK'**. The account name will appear in Access Right list with read/write (R/W) permission (Figure 3.5.5-3). If the access permission of the account needs to be modified, click the **'Edit'** button (pencil icon) on the right side of **'Policy'** column. The option to modify access permission will be shown (Figure 3.5.5-5). There are 2 options: **"R/W"** (read/write) and **"Read Only"**. Set the preferred access mode and click **'OK'** when done.




Figure 3.5.5-4 Select Accounts for Setting Share Permission




Figure 3.5.5-5 Modify Account Policy in the Share

Add Group Permission:

By default, all accounts in the 'users' group are allowed access to the share folders. If you need to assign permission to another group, click '**Group**' button. The Group List window (Figure 3.5.5-6) will appear. Select the name of the Group that will be assigned permission to the share folder and click '**OK**'. The group name will appear in the Access Right list with read/write (R/W) permission. If the access permission of the group needs to be modified, click the '**Edit**' button (pencil icon) on the right side of 'Policy' column. The option to modify access permission will be shown (Figure 3.5.5-7). There are 2 options: "**R/W**" (read/write) and "**Read Only**". Set the preferred access mode and click '**OK**' when done.




Figure 3.5.5-6 Select Groups for Setting Share Permission





Figure 3.5.5-7 Modify Group Policy in the Share


Add IP Permission:

By default, all client IP addresses are allowed access to the share folders. If you need to assign specific client IP, click the **'IP'** button. The Client IP window will appear (Figure 3.5.5-8). Enter the client IP address that will be allowed access to the share folder. Set the Permission, whether **"R/W"** (read/write) or **"Read Only (NFS Only)"**. Click **'OK'** when done. The IP address will appear in the Access Right list (Figure 3.5.5-9). If the access permission of the IP address needs to be modified, click the **'Edit'** button (pencil icon) on the right side of **'Policy'** column. The option to modify access permission will be shown (Figure 3.5.5-8). Set the preferred access mode and click **'OK'** when done.



The 'Client IP' dialog box contains a 'Client IP' text field, a 'Permission' section with two radio buttons ('R/W' and 'Read Only(NFS Only)'), and 'OK' and 'Cancel' buttons at the bottom.

Figure 3.5.5-8 Add Client IP in the Access Right List



The 'Add Share' dialog box shows the 'Access Right' tab. It includes a sidebar with 'Setting', 'Access Right', and 'Conclusion'. The main area displays a table of access rights with columns for ID, Type, Policy, and edit/delete icons. A legend at the top identifies icons for Account, Group, and IP.

ID	Type	Policy		
admin	Account	R/W		
admins	Group	R/W		
users	Group	R/W		
user1	Account	R/W		
group1	Group	R/W		
192.168.100.124	IP	R/W		

Figure 3.5.5-9 Client IP in Access Right List

When Access Right configuration is completed, click 'Next' for confirming the settings. Verify the share folder configuration in the Conclusion page (Figure 3.5.5-10) and make sure all settings correct. Click '**OK**' to save all settings.

Add Share

Setting

Access Right

Conclusion

Setting

Name: share04

Owner: admin

Owner Group : admins

Volume Group: VG01

Logical Volume: LV_1

Permission: ACL

Share Protocol

Window: ☒

Linux: ☐

MAC: ☐

Access Right


ID	Type	Policy
admin	Account	R/W
admins	Group	R/W
users	Group	R/W

Previous Next OK

Figure 3.5.5-10 Conclusion Page Before Creating Share

Edit Share Folder:

Please select the share folder name to be edited from the Share List (Figure 3.5.5-11), and then click 'Edit' icon, the Share Information now can be modified (Figure 3.5.5-12)



Name	Size(GB)	Usage(GB)	Logical Volume	Owner	Owner Group	Window	Linux	MAC	
home	2	0	HOME	admin	admins	✓	✓	✓	✗
share01	100	0	LV_1	admin	admins	✓	✗	✗	✗
share02	100	0	LV_2	admin	admins	✓	✗	✗	✗
share03	100	6.4	LV_3	admin	admins	✓	✗	✗	✗

Figure 3.5.5-11 Share List

Name : The share name is fixed and cannot be edited.


Logical Volume: Shows the Logical Volume name where the share was created from.

Size: The capacity of Logical Volume.

Owner: The share owner, and who always has write permission.

Owner Group: The default group owner of share, and who always has write permission.

Permission: You can set the share access control with or without ACL. If "NoACL" is selected, you can specify the share directory mode as commonly used in Linux systems, like "755", or choose "Public" to allow users access to this share (which also means NoACL mode as "777").



Share Information for share01:

Name: share01 Owner: admin

Logical Volume: LV_1 Owner Group: admins

Size(GB): 100 Permission: ACL

Other Share in this Logical Volume:

Name	Size(GB)	Usage(GB)	Logical Vol.	Owner	Owner Group
share01	100	0	LV_1	admin	admins

Free: 100 GB

Figure 3.5.5-12 Share Information

Share Protocol:

As shown in Figure 3.5.5-13, there are 4 Share Protocol options that can be enabled: CIFS (Samba), NFS, Apple Talk (AFP) and Rsync.




Figure 3.5.5-13 Share Protocol

CIFS

Enable CIFS: Enable and export share for CIFS (Windows) clients.

Case sensitive: Controls whether filenames are case sensitive or not.

WebDAV: When enabled, WebDAV clients are allowed access to the share.

WORM: Write Once Read Many. When this is enabled, all users with permission can only create files but cannot modify or delete it. Only the share owner can delete or modify newly created files.

Hide files that begin with dot: Hide the files that name begin with dot.

Browseable: This option controls whether the share folder will be visible and can be browsed when client PC connects to the NAS. Default setting is enabled. When disabled, and client PC connect to the NAS via CIFS, the share folder will not be visible.

MaxConnection: Set the maximum number of client connection. "0" means no limit.

NFS

Enable NFS: Enable and export share for NFS clients

Allow root access: When this option is enabled, root access to share is allowed.

Synchronize write operation: This option is used to set share IO with synchronous write.

WORM: Write Once Read Many. When this is enabled, all users with permission can only create files but cannot modify or delete it. Only the share owner can delete or modify newly created files.

Insecure: Allows request from IP port larger than 1024.

Subtree Check: Do subtree checking while share is being accessed. Default is Disabled (no subtree checking).

Apple Talk

Enable Apple Talk(AFP): Enable and export share for Apple MAC clients


Time Machine: Enable and export share that can be discovered by "Time Machine" backup application in MAC.

Rsync

Account: Set the user name that will be used for share login via Rsync.

Password: Set the password that will be used for share login via Rsync.

Edit Access Right:

You can modify share permission in the "Access Right" tab by clicking Account/Group/IP in the list (Figure 3.5.5-14), or clicking "Account/Group/IP" at the top to assign new permission. If you want to remove the account/group/IP assigned in the share, just click  at the right-most column of the ID to be removed.






Figure 3.5.5-14 Share Access Right

Delete Share Folders:

In the Share List, click the delete icon  (Figure 3.5.5-15) on the right of the Share Folder name to be deleted. The Confirmation window (Figure 3.5.5-16) will be displayed. Select the "Confirm:" option and click 'Yes' to continue deleting the selected share folder.



Name	Size(GB)	Usage(GB)	Logical Volume	Owner	Owner Group	Window	Linux	MAC	
home	2	0	HOME	admin	admins				
share01	100	0	LV_1	admin	admins				
share02	100	0	LV_2	admin	admins				
share03	100	6.4	LV_3	admin	admins				

Figure 3.5.5-15 Share list




Figure 3.5.5-16 Confirm Message to Delete Share

3.6 Service Manger



3.6.1 Samba service

Samba provides SMB/CIFS file and printer sharing. This service needs to be enabled so that MS Windows systems can access NAS share folders or printer.

Samba

Samba provide local shared directory and Windows systems with each other to share files and printers.

☒ Enable

☐ strict allocate

☒ unix extensions

Port:

Security Mode:

Recycle Bin

☐ Enable

Logical Volume:

Days to keep:

After enable service, please to set config in the "share protocol". >>> [Share List](#)

Audit

☐ Enable

Logical Volume:

Days to keep:

After enable service, please to set config in the "share protocol". >>> [Share List](#)

Printer

☐ Enable

Printer Model: None

Figure 3.6.1-1 Samba Options

Enable: To start Samba service, select the 'Enable' option. To stop this service, unselect this option. Modify other options if necessary. Click 'Apply' when done,

Strict allocate: This option controls the handling of logical volume space allocation. When disabled (default setting is disabled or un-checked), the system does not sparse logical volume block allocation when a file is extended. To enable this option, select it and click 'Apply'.

Unix extensions: Default is enabled. To disable this option, deselect (uncheck) it and click 'Apply'.

Port: Default is 445. There are 3 options: 445, 139, and '445,139'

Security Mode: Default is set to USER. There are two options available for setup: USER, SHARE

Recycle Bin: This option allows deleted files from the NAS share folder to be retained in the Recycle Bin share folder.

To enable Recycle Bin, select the 'Enable' option, and then select the logical volume that will be used to store the Recycle Bin data. Setup the 'Days to keep:' option for the number of days you want to keep the deleted files in the Recycle Bin. Click 'Apply' when setup is done. The Recycle Bin function will be enabled.

Audit: This option provides record of all user access to share folder data. Some examples of information are add/delete/modify record.

To enable Audit, select the 'Enable' option, and then select the logical volume that will be used to store the Audit information. Setup the 'days to keep:' option for the number of days to retain Audit information. Click 'Apply' when setup is done. The Audit function will be enabled.

Printer: Enable this option to connect and detect a USB printer and share it to clients.



NOTE: For detailed options, please edit Share Protocol in Share manager.

3.6.2 NFS service

NFS provides Network File System file sharing. This service must be enabled so that UNIX and Linux systems will be able to access (mount) the NAS share folders.




Figure 3.6.2-1 NFS Options

Enable: To start NFS service, select the 'Enable' option, or unselect this option to stop service, Choose the NFS version option if needed. Click 'Apply' when done.

Enable NFSv4: Default is disabled. To enable support for NFS version 4, select this option.

Enable NFS v2, v3: Default is enabled, which means NFS version 2 and version 3 are supported. To disable this option, deselect it (check mark will disappear).



NOTE: The detailed options please edit Share Protocol in Share manager.

3.6.3 AFP service

AFP provides file services for Mac OS X and original Mac OS. This service need to be enabled so that Mac OS users will be able to access the NAS share folders vi AFP.




Figure 3.6.3-1 AFP Options

Enable: To start AFP service, select the 'Enable' option and the click 'Apply'. To stop this service, unselect option and clicn 'Apply'.



NOTE: The detailed options please edit Share Protocol in Share manager.

3.6.4 FTP service

FTP is a standard network protocol used to transfer files to/from NAS from/ to another host over a TCP-based network. After this service is enabled, NAS accounts can be used to login NAS and access share folders via FTP.

Enable: To start FTP service, select the 'Enable' option. If necessary, modify the Port and Max Connections options. Click 'Apply' when done.

To stop this service, unselect this option and click 'Apply'.

Port: Default port used by FTP is 21. If modified, select from range 1024 to 65534.

Max connections: Default maximum number of FTP connections is 10. If modified, number can be changed up to 1000.

Type: Select option: FTP (general support only), FTP over explicit TLS/SSL, or Both

SFTP: Select to enable SFTP (Secure FTP), please note that SSH service will also be enabled when SFTP selected.

FTP

FTP is a standard network protocol used to transfer files from one host to another host over a TCP-based network, such as the Internet.

☐ Enable

Port: 21

Max Connections (0 is Unlimited): 10

Type: FTP

SFTP

☐ Enable

When SFTP service is enabled, SSH service will be enabled at same time.

After enable service, please to set config in the "Account". >>> **Account**

Apply

Figure 3.6.4-1 FTP Options

3.6.5 WebDAV service

WebDAV protocol makes the Web a readable and writable medium. It provides a framework for users to create, change and move documents on a server; typically a web server or web share.




Figure 3.6.5-1 WebDAV Options

Enable : Select and click 'Apply' to start WebDAV service. To stop service, unselect this option and click "Apply".

SSL Support : Disable or enable HTTPS support.

3.6.6 TFTP service




Figure 3.6.6-1 TFTP Options

Enable: To start TFTP service, select the 'Enable' option and then choose a share folder (must be a share folder set as "Public"). Click 'Apply' when done. To stop service, unselect this option and click 'Apply'.

3.6.7 Rsync service

Rsync is a file transfer program which provides copying and updating files to/from NAS share folder from/to a remote Rsync host, such as another NAS.




Figure 3.6.7-1 Rsync Options

Enable: To start Rsync service, select the 'Enable' option and click 'Apply'. To stop service, unselect this option and click 'Apply'.

3.6.8 Bonjour service

Bonjour provides a general method to discover services in the LAN. It is designed to help devices and applications discover each other on the same network.



Figure 3.6.8-1 Bonjour Options


Enable: To start Bonjour service, select the 'Enable' option and click 'Apply'. To stop service, unselect this option and click 'Apply'.

3.6.9 SNMP service

SNMP is used mostly in network management systems to monitor network-attached devices for conditions that warrant administrative attention.

Start SNMP Service: To enable SNMP service, select the 'Enable' option. Choose the SNMP version if necessary. By default, SNMP version 1 and 2 is enabled. Click 'Apply' when done.

Enable SNMP v3: To enable support for SNMP version 3, select the 'Enable snmp v3' option, then setup Auth Protocol, Auth Password, Priv Protocol, and Priv Password. Click 'Apply' when done.



The image shows a configuration window titled "SNMP". At the top, there is a checkbox labeled "Enable". Below this, there are two sections. The first section is titled "snmp v1,v2" and contains a checked checkbox labeled "Enable snmp v1,v2" and a text field labeled "Community:" with the value "public". The second section is titled "snmp v3" and contains an unchecked checkbox labeled "Enable snmp v3". Below this checkbox are four fields: "Auth Protocol:" with a dropdown menu showing "MD5", "Auth Password:" with an empty text field, "Priv Protocol:" with a dropdown menu showing "DES", and "Priv Password:" with an empty text field. At the bottom right of the window is an "Apply" button.

Figure 3.6.9-1 SNMP Options

3.6.10 DHCP service

DHCP service enables the NAS to function as DHCP server and provides automatically assigned IP address to other computers in the internal network or LAN.

Figure 3.6.10-1 DHCP Options

Enable: To start DHCP service, select the 'Enable' option. Modify the other settings as necessary. Click 'Apply' when done. The DHCP service will be started and the NAS system will act as DHCP server, providing dynamic IP addresses to client PCs. To stop service, unselect this option and click 'Apply'.

LAN: Select the LAN interface that is connected to private/internal network, the same network segment as the client PCs.

WAN: Select the LAN interface that is connected to public/external network, the same network segment that has internet/WAN connection.

Start Range of IP: Enter the starting IP address of the range of addresses (dynamic IP) for the private/internal network.

Ending Range of IP: Enter the ending IP address of the range of addresses (dynamic IP) for the internal network.

3.6.11 SSH service

SSH (Secure Shell) is a network protocol that allows data to be exchanged using an encrypted and secure channel between the NAS and a remote host.




Figure 3.6.11-1 SSH Options

Enable: To start SSH service, select the 'Enable' option and click 'Apply'. To stop service, unselect this option and click 'Apply'.

3.6.12 Telnet service

Telnet is a network protocol used on the Internet or local area networks to provide a bidirectional interactive text-oriented communication facility using a virtual terminal connection.




Figure 3.6.12-1 Telnet Options

Enable: To start Telnet service, select the 'Enable' option. If necessary, modify the Port and Max Connections options. Click 'Apply' when done. To stop service, unselect this option and click 'Apply'.

Port: Default port used by Telnet is 23. If modified, select from range 1024 to 65534.

Max connections: Default maximum number of Telnet connections is 10. If modified, number can be up to 1000.

3.6.13 File Manager

File Manager provide NAS user accounts access to NAS share folders and files via web GUI.





Figure 3.6.13-1 File Manager Options

Enable: To start File Manager service, select the 'Enable' option and click 'Apply'.
To stop service, unselect this option and click 'Apply'.

More information about File Manager please see Chapter 3.11.

3.7 Account Manager

3.7.1 Account



Login Name	Full Name	UID	Quota	Directory	FTP Folder	E-Mail	Status
admin	administrator	50	0	Local	Personal	admin@mail.com	

Account Manager interface showing a table with account details. The table has columns: Login Name, Full Name, UID, Quota, Directory, FTP Folder, E-Mail, and Status. The first row shows an account named 'admin' with full name 'administrator', UID 50, Quota 0, Directory Local, FTP Folder Personal, E-Mail admin@mail.com, and Status Active (indicated by a green checkmark). The interface also includes buttons for Add, Edit, Import Account, and Export Account, a search bar, and pagination controls at the bottom.

Figure 3.7.1-1 Account List

Add Account: To add a new account, click 'Add' button in Account Manager. The 'Add new account' window will appear. Follow the 'Add new account' setup wizard (Figure 3.7.1-2) .

Account Setting: Enter the account information such as Login Name, Full Name, Password, and other necessary settings. When done, click 'Next' to go the next setup page 'Assign Share'.



The 'Add new account' window displays the 'Account Setting' tab. It contains the following fields and options:

- Login Name:** LocalUser0
- Full Name:** LocalUser0
- UID:** 1001
- Quota(GB):** 1 (Range: -1 : 1MB, 0 : Unlimit)
- FTP Folder:** share
- Directory:** Local
- Password:** (masked with dots)
- Password Confirm:** (masked with dots)
- E-Mail:** default@mail.com
- Status:** Active

Navigation buttons at the bottom: Previous, Next, Cancel.

Figure 3.7.1-2 Add New Account Setting

Login Name: Please enter the account name. Account name allows up to 32 characters and can only contain letters, numbers, hyphen (-), and underscore (_). A space or period (.) is not allowed.

Fully Name: Enter a full name or a descriptive name for the account.

Quota (GB): Set the quota/limitation for the account's personal (home) folder. To disable (turn off) the quota for the account's personal folder, set the value to "-1". To set the quota to no limit, set the value to "0".

FTP Folder: Select the default FTP folder for the account. This option will direct the user account to the selected share folder, when user account login via FTP. Options include all existing share folders, Personal, and All.

Directory: This information is set by the system automatically. When an account is created in the NAS system, this field will show 'Local'.


Password: Enter password for the account. Password can contain at least 6 characters, can be up to 32 characters, and can only contain letters, numbers and special characters _ - ~! @ # \$% ^ & *. The following characters cannot be used [] {} ().

Password Confirm: Enter the same password again.

E-mail: Enter e-mail address for this account.

Status: Default is 'Active' or enabled. If administrator wants to disable this account, set this to 'Inactive'.

Assign Share: Select the share folders that this account can access, and click 'Next' to go to the next page "Conclusion".



Add new account

Account Setting

Assign Share

Conclusion

<input checked="" type="checkbox"/>	Name	Usage	Logic Volume	Owner
<input checked="" type="checkbox"/>	share	0	share	admin
<input checked="" type="checkbox"/>	share01	0	LV_0	admin

Previous Next Cancel

Figure 3.7.1-3 Add New Account, Assign Share Setting

Conclusion: Verify that the account settings are correct. Click 'OK' when done. The new account will be created.



Add new account

Account Setting

Assign Share

Conclusion

Login Name: LocalUser0

Full Name: LocalUser0

UID: 1001

Quota: 1

FTP Folder: share

Directory: Local

Password:

E-Mail:

Create Time: 2012/09/10 07:37:28

Status: Active

Assign Share

Previous Next OK

Figure 3.7.1-4 Confirm Information to Create a New Account

Edit: To edit an account, select the account name in the Account Manager's list, and click 'Edit'. The Account Setting page will appear. Modify the settings if necessary. Click 'Next'.

The screenshot shows the 'Edit Account' window with the 'Account Setting' tab selected. The sidebar on the left contains three items: 'Account Setting' (highlighted), 'Assign Share', and 'Conclusion'. The main content area displays the following fields and their current values:

Login Name:	LocalUser0
Full Name:	LocalUser0
UID:	1000
Account folder quota(GB): (-1 : 1MB, 0 : Unlimit)	1
FTP Folder:	Personal
Directory:	Local
Password:	*****
Password Confirm:	*****
E-Mail:	default@mail.com
Status:	Active

At the bottom of the window, there are three buttons: 'Previous', 'Next', and 'Cancel'.

Figure 3.7.1-5 Edit Account

The step to modify account is just like the step to create account, but some options like Login Name, Full Name and UID are disabled and cannot be modified.

Conclusion: Verify that the account settings are correct. Click 'OK' when done. The system will update the new settings for the account.

Edit Account

Account Setting

Conclusion

Assign Share

Conclusion

Login Name: LocalUser0

Full Name: LocalUser0

UID: 1000

Quota: 1

FTP Folder: Personal

Directory: Local

Password: *****


E-Mail:

Create Time: 2013/05/08 02:06:22

Status: Active

Previous Next OK

Figure 3.7.1-6 Confirm Information to Edit Account

Delete Account: Click the delete icon  on the right of the account name to be deleted (Figure 3.7.1-7). The confirmation window will be displayed. Select the "Confirm:" option and click 'Yes' (Figure 3.7.1-8). The account name will be deleted.

Account Manager

Add Edit Import Account Export Account Search:

Login Name	Full Name	UID	Quota	Directory	FTP Folder	E-Mail	Status
admin	administrator	50	0	Local	Personal	admin@mail.com	
LocalUser1	LocalUser1	1001	1	Local	Personal		
LocalUser0	LocalUser0	1000	1	Local	Personal		

Figure 3.7.1-7 Account Manager, Account List


Confirm

Are you sure you want to delete LocalUser0

Confirm: ☐

Yes No

Figure 3.7.1-8 Confirm Information to Delete Account

Import Account: In Account Manager (figure 3.7.1-7), click the 'Import Account' button. The Import Account window will appear. Click the 'select file' icon , and select the file (extension must be CSV) containing the account list that will be imported to the NAS system. Click 'OK' when done. The accounts will be automatically added to the Account list.




Figure 3.7.1-9 Import Account

Format of each Account Entry:

UID,Login Name>Password,Full Name,Quota,Group Name




NOTE: Each field in an account entry must be separated by comma, and there should be no space between commas. In the CSV file, each account entry must be in one line.

For example:

```
1001,Tony,1qazxsw2,Tony Lee,10,Sales
1002,Scott,qwerty123,PM Scott,10,PM
```

Export Account: Click the 'Export Account' button. Save the account file (default file name is "nasaccount.csv") to your client computer. The account file can be used later for account recovery/import.

3.7.2 Group



The screenshot shows the 'Group Manager' window. It has a title bar with 'Add' and 'Edit' buttons. Below the title bar is a search bar. The main area is a table with columns: Name, GID, Directory, and Describe. The table contains three rows: 'admins' with GID 50 and Directory 'Local'; 'users' with GID 100 and Directory 'Local'; and 'LocalGroup0' with GID 1000 and Directory 'local'. The 'Describe' column for 'LocalGroup0' contains the text 'Local Group'. There are red minus icons in the right margin of the table.

Name	GID	Directory	Describe
admins	50	Local	
users	100	Local	
LocalGroup0	1000	local	Local Group

Figure 3.7.2-1 Group Manager, Group list

Add New Group: Click 'Add' button. The Add Group window will appear. Setup the Group Setting.

Name: Enter the name for the local group. The group name allows up to 32 characters and can only contain letters, numbers, hyphen (-), and underscore (_). A space or period (.) is not allowed.

GID: System default value starts with 1000. If needed to assign other GID (group ID), select the preferred GID using the arrow-down or arrow-up button. Duplicate GID is not allowed.

Describe: Enter a description for the new local group.

Add Account to Group: Select the account name that you want to join to the group by using the mouse and dragging the account name from Account List into the Group Member pane. When done, click 'Next' to go to Conclusion page.

Remove Account from Group: In Group Member list, select account name you want to remove the group, and use the mouse to drag the account from the Group Member pane to the Account List pane on the left side. When done, click 'Next' to go to Conclusion page.

Add Group

Group Setting

Setting

Name: LocalGroup0

GID: 1000

Describe: Local Group

Account List

Search:

Login Name	Full Name	UID
admin	administrator	50
test	LocalUser0	1001

Group Member

Login Name	Full Name	UID
------------	-----------	-----

Page 0 of 0

Previous Next Cancel

Figure 3.7.2-2 Add New Group

Conclusion: Verify settings for the new group if correct. Click 'OK' when done. The new group will be created.

Add Group

Conclusion

Setting

Name: LocalGroup0

GID: 1000

Describe: Local Group

Group Member

Login Name	Full Name	UID
test	LocalUser0	1001

Page 0 of 0

Previous Next OK

Figure 3.7.2-3 Confirm Message to Create Group

Edit Group: In the Group Manager list (Figure 3.7.2-1), click the group name to be edited and then click 'Edit' button. The following window will appear.

Group Setting

Setting

Name: LocalGroup0

GID: 1000

Describe: Local Group

Account List

Search:

Login Name	Full Name	UID
admin	administrator	50

Group Member


Login Name	Full Name	UID
LocalUser0	LocalUser0	1000
LocalUser1	LocalUser1	1001

Drag account into group table for add, Drap out account from group table for remove.

Previous Next Cancel

Figure 3.7.2-4 Edit Group

The step to modify group is just like the step to create group, but some options like Name and GID are disabled and cannot be modified.

Delete Group: Click the delete icon  on the right side of the group name to be deleted (Figure 3.7.2-1). The confirmation window will be displayed (Figure 3.7.2-5). Select the "Confirm:" option and click 'Yes' button. The group will be deleted.

Confirm

Are you sure you want to delete LocalUser0

Confirm: ☐

Yes No

Figure 3.7.2-5 Confirm Message to delete Group

3.7.3 Directory Service

Enable ADS Authentication:

To start the Windows directory service ADS, select this option. Configure the ADS settings. When done, click 'Apply' button. The NAS system will be joined to the Windows domain, and ADS accounts and groups will be shown in the Account and Group list in the NAS system. Administrator can then assign share folder permission to these ADS accounts and groups.

Figure 3.7.3-1 Enable ADS Authentication

Automatic detect Domain IP:

Default is enabled. To use this option, DNS must be set first in "System Manager" → "Network" → "DNS". If system does not automatically detect the domain server IP, this option can be disabled, and then the domain server IP address can be manually entered in the "Domain Server IP" box.

Synchronize time to ADS:

Default is enabled. NAS system will synchronize time from ADS domain server. If administrator wants to synchronize time from NTP Server, this option must be disabled and NTP Server must be setup in "System Manager" → "General" → "Date/Time".



NOTE: When NAS system is set to synchronize time from NTP Server, the ADS domain server must also synchronize time from the same NTP Server to avoid desynchronized time between ADS server and NAS system, which can result in failure to join the NAS to ADS domain.

Auto Detect Entypes:

Default is enabled which means the NAS will automatically detect the encryption type. If ADS Server is using a special password encryption mode, please disable this option and select the appropriate encryption mode from "EncType" field. Click first the arrow-down button on the right to see the various encryption mode options.

Entype: After "Automatic Detect Entypes" is disabled, this function will be enabled.

Domain/Workgroup: Enter the domain name, for example: MYDOMAIN, or enter the workgroup name.

DNS Suffix: Enter the fully qualified domain name. For example: MYDOMAIN.COM

Doman Server IP: The "Automatic detect Domain IP" option must be disabled, and then the domain server's IP address can be manually entered here.

Enable NTLMv2 authentication: Default is disabled. To enable NTLMv2 authentication, select this option.

Enable client schannel: Default is enabled.

Logon Account (Administrator): Enter the domain administrator's account name.

Password: Enter the password for the domain administrator's account name.

PDC/ADS Mode: Select the domain server mode, ADS or PDC. ADS include Windows 2000, 2003, and 2008 Server, and PDC includes Windows NT Sever.

Account Quota (GB): Set the quota/limitation for the domain account's personal (home) folder. To disable (turn off) the quota for the domain account's personal folder, set the value to "-1". To set the quota to no limit, set the value to "0".

FTP Folder: Select the default FTP folder for the domain account. This option will direct the domain account to the selected FTP share folder, when user account login via FTP.

Enable NIS Authentication:

To start the NIS directory service, select this option and set the following information below. Click 'Apply' when done. The NIS domain accounts and groups will be added in Account and Group list, and then administrator can set share folder access permissions to the accounts or groups.

NIS Domain: Enter the NIS domain name

NIS Server: Enter NIS Server IP address.




Figure 3.7.3-2 Enable NIS Authentication

Enable LDAP Authentication:

To start the LDAP directory service, select this option and set following information below. When done, click '**Apply**'. The LDAP accounts and groups will be added to the Account and Group list, and then administrator can set share folder access permissions to the accounts or groups.

LDAP server DC suffix: Enter the LDAP DC suffix. For example:

dc=ldapserver,dc=com

LDAP server IP: Enter the LDAP Server IP address.

LDAP admin DN: Enter the LDAP administrator DN. For example:

cn=admin,dc=ldapserver,dc=com

LDAP admin password: Enter the LDAP administrator password.



NOTE: If administrator wants to use LDAP accounts and groups to be assigned Samba share folder access, administrator must start first in the LDAP server the Samba account schema and then start the LDAP directory services in NAS. If Samba account schema is not activated in LDAP server, the NAS system can only use LDAP server's accounts and groups to be assigned share folder access via FTP.




Figure 3.7.3-3 Enable LDAP Authentication

3.8 Backup Manager



3.8.1 Data Backup

The Data Backup pack all selected files into a single backup file, and it supports full, incremental and differential backup of specified share folder containing data, and also supports scheduled backups. Supported backup destinations are: Local Share folder in NAS, External Devices such as USB external disk, Samba (SMB/CIFS) remote share folder, and NFS remote share folder.

Data Backup						
➕ Add ✎ Edit ✖ Delete 🔄 Refresh						
Plan Name	Destination	Backup Mode	Last Backup Time	Next Backup Time	Status	
test	Local Share	Full Backup	2013-05-20 20:40:48	--	Running	▶ ✖
➕ Show All Plan Backup Record						
Plan Name	Start Time	Finish Time	Destination	Backup File	Result	
test	2013-05-20 20:40:48	2013-05-20 20:40:49	/vol/LVB1/share01	test-full-2013-05-20-...	Backup is finish	📁

Figure 3.8.1-1 Data Backup Plan List

Add Backup Plan: Click the '**Add**' icon. The Add Backup window will be displayed.

Step 1: Configure the basic settings, such as plan name, destination, and mode.

Plan Name: Enter the name of the backup plan. The plan name allows up to 32 characters, and can only contain letters, numbers, hyphen (-), and underscore (_). Space and period (.) is not allowed. Duplicate backup plan name is also not allowed.

Destination Description:

Destination	Setting	Description
Local Share (Figure 3.8.1-2)	Share folder	NAS Local share folder
External Devices (Figure 3.8.1-3)	Ext_Device	USB / eSATA Disk
	Format	EXT3/NTFS/Not format
Samba (Figure 3.8.1-4)	IP	Remote Samba/CIFS share folder IP address
	Account	Login account
	Password	Login password
	path	Remote Samba/CIFS share folder name
NFS (Figure 3.8.1-5)	IP	Remote NFS computer IP address
	Path	Remote NFS share folder name

Add Backup

Plan Name:

Destination Type:

Destination Detailed Setting

Share Folder:

Backup Mode: ☒ Full Backup
☐ Incremental(Will use less backup space, but the restore process is slower.)
☐ Differential(Will use more backup space, but the restore process is faster.)

Figure 3.8.1-2 Add a Plan to Backup to a Local Share

The 'Add Backup' dialog box is shown with the following settings:

- Plan Name: test
- Destination Type: External Devices
- Destination Detailed Setting:
 - External Device: sdc(1.92GB)
 - Format: NTFS
- Backup Mode: ☒ Full Backup, ☐ Incremental(Will use less backup space, but the restore process is slower.), ☐ Differential(Will sse more backup space, but the restore process is faster.)

Figure 3.8.1-3 Add a Plan to Backup to Local External Device

The 'Add Backup' dialog box is shown with the following settings:


- Plan Name: test
- Destination Type: Samba
- Destination Detailed Setting:
 - IP: 192.168.100.120
 - Account: admin
 - Password:
 - Directory: public
 - Directory Ex: BackupFolder
- Backup Mode: ☒ Full Backup, ☐ Incremental(Will use less backup space, but the restore process is slower.), ☐ Differential(Will sse more backup space, but the restore process is faster.)

Figure 3.8.1-4 Add a Plan to Backup to Remote Samba (CIFS) Share

Figure 3.8.1-5 Add a Plan to Backup to Remote NFS Share

Backup Mode: Default mode is a Full Backup. There are three options: Full Backup, Incremental, and Differential

After setup is completed, click '**Next**' to choose the share folder to be backed up.

Step 2: From the Source File, select the file(s) or share folder(s) to be backed up. Then click the Add icon . The selected file(s) or share folder(s) will be added to the Backup File list. Click 'Next' to go to the Backup Plan Summary page for confirmation.

Name	Type	Path
share01	folder	/LV_0/share01

Figure 3.8.1-6 Step 2: Select Share Folder or File to Add to the Backup File List

Step 3: In Backup Plan Summary page, check the backup plan setup if correct or need to be modified. Click 'OK' when done. The new backup plan will be created.

Add Backup

Backup Plan Summary

Plan Name: test01

Destination: Local Share

Share Folder: share

Backup Mode: Full Backup



Backup File

Name	Type	Path
share01	folder	/LV_0/share01

Previous OK Cancel

Figure 3.8.1-7 Step 3: Confirm to Add New Backup Plan

Restore:

Select the backup plan name or click '**Show All Plan Backup Record**', and previous backup records will be shown (Figure 3.8.1-8). To restore a previous backup record, click the restore icon  on the right side. A confirmation screen will appear. Make sure the destination folder has enough space. Click 'Yes' to confirm. The Restore Backup page (Figure 3.8.1-9) will appear. Select the folders or files you want to be restored and click the Add icon . The selected files or folders will appear on the Restore File list. Finally select the destination share folder in '**Destination**'. Click '**Restore**' when done. The backup data will be restored to the specified destination share folder.

Data Backup						
Add Edit Delete Refresh						
Plan Name	Destination	Backup Mode	Last Backup Time	Next Backup Time	Status	
test	Local Share	Full Backup	2013-05-20 20:40:48	--	Running	
Show All Plan Backup Record						
Plan Name	Start Time	Finish Time	Destination	Backup File	Result	
test	2013-05-20 20:40:48	2013-05-20 20:40:49	/vol/LVB1/share01	test-full-2013-05-20-...	Backup is finish	

Figure 3.8.1-8 Data Backup Plan List and Record List





Figure 3.8.1-9 Select the Share Folders and/or Files to be Restored

Edit: Select the backup plan name you want to be modified and click 'Edit'. Click 'Next' to modify the backup plan.

Edit Backup Source File: Under 'Source File' list, select the file or share folder you want to be added for backup and click the Add icon . The selected file or folder will appear on the 'Backup File' list on the right. To delete a file or folder from Backup File list, click the delete icon on the right of the file or folder. When done, click 'Next' to go to Back Plan Summary page.

Back Plan Summary: Check the backup plan setup if correct or still need to be modified. Click 'OK' when done. The backup plan settings will be updated.

Delete Backup Plan: Click the delete icon  on the right side of the backup plan name to be deleted (Figure 3.8.1-1). The Confirm window will appear. Click 'Yes' to confirm deletion of the selected backup plan.

The backup plan can also be defined with scheduled job in Schedule manager.
(See Chap 3.4.8)

3.8.2 Data Copy

Data Copy is similar to Data Backup but doing only 1:1 copy to another destination. It creates a full and exact copy of the selected data. The Share Copy backup function supports full copy backup of selected shared folder to backup destination device. It also supports scheduled backup for automatic backup. Supported backup destinations are: Local Share folder in NAS, External Devices such as USB external disk, Samba (SMB/CIFS) remote share folder, and NFS remote share folder.

Data Copy

Add

Edit

Delete

Refresh

Plan Name	Destination	Last Backup Time	Next Backup Time	Status		
dtestp1	Local Share	2013-05-13 20:31:11	--	Enable		

Show All Plan Backup Record

Plan Name	Start Time	Finish Time	Destination	Result
dtestp1	2013-05-13 20:31:11	2013-05-13 20:32:37	/vol/share/share01	Share copy is finish

Figure 3.8.2-1 Data Copy Plan and Record List

The backup plan can also be defined with scheduled job in Schedule manager. (See Chap 3.4.8)

Add Share Copy Backup: Click the 'Add' icon. The Add Backup window will appear.





Figure 3.8.2-2 Step 1: Add a New Data Copy Plan

Step 1: Configure the basic backup plan settings, such as plan name and destination. Click 'Next' when done.

Plan Name: Enter the name of the backup plan. Plan name allows up to 32 characters, and can only contain letters, numbers, hyphen (-), and underscore (_). Space or period (.) is not allowed. Duplicate backup plan name is also not allowed.

Destination	Setting	Description
Local Share	Share Folder	NAS Local share folder
External Devices	Ext_Device	USB Disk
	Format	EXT3/NTFS /Not format. If set as EXT3 or NTFS, in the first backup, system will format the external device as EXT3 or NTFS. If set as "Not format", system will automatically recognize the external device's file system format after auto-mount.
Samba	IP	Remote Samba/CIFS share folder IP address
	Account	Login account
	Password	Login password
	Path	Remote Samba/CIFS share folder name
NFS	IP	Remote NFS share folder IP address
	Path	Remote NFS share folder name

Step 2: Select the share folder or file to be backed up from Source File, and click the Add button . The selected share folder or file will appear on the Backup File list in the right. Click 'Next' to go to Backup Plan Summary confirmation page.




Figure 3.8.2-3 Step 2: Select Share Folder or File to Add to Backup File List

Step 3: In Backup Plan Summary page, check the backup plan setup if correct or need to be modified. Click 'OK' when done. The new backup plan will be created.

Add Backup

Backup Plan Summary

Plan Name:

Destination Type:

Share Folder:


Backup File

Name	Type	Directory
lib	folder	/share/share/lib
test.imb	file	/share/share/test.imb


Previous OK Cancel

Figure 3.8.2-4 Step 3: Confirm to Add the New Backup Plan

Edit: Select the backup plan that you want to edit, and then click 'Edit' icon. Click 'Next' to modify the backup plan.

Edit Backup Source File: Under 'Source File' list, select the file or share folder you want to be added for backup and click the Add icon . The selected file or folder will appear on the 'Backup File' list on the right. To delete a file or folder from Backup File list, click the delete icon on the right of the file or folder. When done, click 'Next' to go to Back Plan Summary page.


Back Plan Summary: Check the backup plan setup if correct or still need to be modified. Click 'OK' when done. The backup plan settings will be updated.

Delete Back Plan: Click the delete icon  on the right side of the backup plan name to be deleted (Figure 3.8.2-1). The Confirm window will appear. Click 'Yes' to delete the selected plan.

The backup plan can also be defined with scheduled job in Schedule manager. (See Chap 3.4.8)

3.8.3 Replication Backup


Replication Backup supports block-level replication of data from one logical volume of a NAS system to another logical volume of another NAS system. The two logical volumes, which are setup with Replication Backup, will be similar to a mirrored logical volume or Raid Level 1, and this enhances the logical volume data protection. When data is written on the source NAS logical volume, the data in the destination NAS logical volume is automatically synchronized. If the source NAS fails, administrator can manually switch and connect directly to the second NAS for continued data access.



Logical Volume	Port	Remote IP	Remote VG	Status
LV_6	5000	192.168.12.121	VG01	Replication need initial

Figure 3.8.3-1 Replication Backup List

Add Replication Backup: Click 'Add'. The Add Replication window will be displayed. Set the options below and click 'OK' when done.



Add Replication

Logical Volume: LV_6

Interface: LAN_1

Remote VG: VG01

Port: 5000

Sync Rate(MB/s): 30

Connect Type: Sync

Local IP: 192.168.12.120

Remote IP: 192.168.12.121

Buffer Size(KB): 512

Time Out(Sec): 6

Lost Connect: Reconnect

OK Cancel

Figure 3.8.3-2 Add New Replication Backup

Logic Volume: Select which Volume will be replicated

Interface: Select which NAS Ethernet port will be used for Replication connection

Local IP: Displays the local (source) NAS IP address that will be used for Replication.

Remote VG: Enter the VG name on the remote (destination) NAS where the replicated logical volume will be created

Remote IP: Manually enter the remote (destination) NAS IP address that will be used for Replication.

Port: Select a TCP port to bind locally and will be used to connect to the remote NAS.

Buffer Size (KB): It is the size of the TCP socket send buffer. You can specify smaller or larger values. Larger values are appropriate for reasonable write throughput with asynchronous protocol over high latency networks. Default is 512K and maximum is 2048K.

SyncRate (MB/s): This sets the limit of the bandwidth that will be used by the synchronization process. Default is 30MB/sec. Minimum value is 10MB/sec and maximum value is 1000 MB/sec – for high latency network environment (e.g. bonding on Gigabit Ethernet).

Time Out (Sec): It is the value to wait for connection timeout if the remote NAS has failed. If the remote NAS fails to send the response packet within the specified timeout time, the remote NAS will be considered dead and the TCP/IP connection is abandoned. The default is 6 sec. Minimum is 1 sec and maximum is 60 sec

Connection Type: There are two types of Replication Backup Connection:

Sync (Synchronous) - The system will acknowledge the transaction as completed after the data is written to the logical volume of destination NAS. It is recommended to use this mode. In most cases, this connection type preserves transaction semantics. Write IO is reported as completed if it has reached the remote logical volume.

Async (Asynchronous - for high latency network) - The system will acknowledge the transaction as completed after the data is written to system buffer. It provides faster transmission and is suitable for busy network. Write IO is reported as completed if it has reached the local TCP send buffer.

Lost Connect: When connection is lost, the Replication Backup can either go to stand-alone mode or will try to reconnect.

Reconnect: The Replication Backup will attempt to reconnect. (Default)

Stand-alone: The Replication Backup will not attempt to reconnect and will be in stand-alone state. All IO requests are only passed locally and no replication.



NOTE: Before Replication Backup is successfully created, a 4GB logical volume will be created on each NAS. This will serve as the metadata device for the replicated volume. This volume is not mounted and will not be seen on the NAS GUI. Please be sure to have an extra 4GB available VG space on both source and destination NAS.

Initialize or Edit Replication: Select the Logical Volume name in Replication Backup list, and then click 'Edit'. The Edit Replication window will appear.

Figure 3.8.3-3 Modify Replication Backup

Initial Replication: Click "Initial Replication" to initialize the Replication Backup for the selected Logical Volume.

Replication Backup				
Add Edit				
Logical Volume	Port	Remote IP	Remote VG	Status
LV_6	5000	192.168.12.121	VG01	cs:SyncSource 6.1% ro:Primary/Secondary ds:UpToDate/Inconsistent finish: 0:05:12 speed: 31,540 (31,540) K/sec

Figure 3.8.3-4 Replication Backup Status



NOTE: After setup of Replication Backup on a logical volume in source NAS, a similar logical volume will be automatically created on the destination NAS under the specified VG. At this point, the Replication Backup is not yet initialized and no synchronization. Replication Backup still needs to be initialized first. After selecting "Initial Replication" button, the source NAS will then connect to the destination NAS and starts to synchronize. Synchronization typically takes quite a while especially on larger logical volume. After initialization, the source NAS should be in "Primary" state and the destination NAS should be in "Secondary" state. If this is the state, you have now a working Replication Backup. Initializing the Replication is done in the source NAS.

Set Primary: To set the replicated logical volume in destination (Secondary) NAS to be Primary, both NAS must be set first to Secondary state. This can be done by setting the Primary NAS to be Secondary. After both NAS becomes Secondary/Secondary, go to the NAS GUI of the destination NAS. Edit the replicated logical volume and use the "Set Primary" button.

Set Secondary: To set a Primary (source) logical volume to be Secondary (destination), use the "Set Secondary" button on the Primary NAS.

Force Sync: To manually force the synchronization, click the "Force Sync" button. The data on the primary NAS will be forcefully synchronized to the secondary NAS.

Reconnect: To reconnect a broken Replication Backup connection, click the "Reconnect" button. At some point in time, if Replication Backup fails to establish connection to the other NAS, you may try to re-establish connection thru this button. This button will be enabled only if one of the NAS losses connection.

Abort Replication: To abort or drop the replication, click the "Abort Replication" button. After aborting replication, the data on the destination logical volume (Secondary NAS) can be retrieved by accessing the share folder under that destination logical volume, and the share folder name is exactly the same as the share folder on the source logical volume (Primary NAS).



NOTE: Snapshot and Thin Provisioning volumes do not support Replication.

Extending Logical Volume Size under Replication Backup

The following are the steps:

1. Abort the Replication Backup by selecting "**Abort Replication**" button.
2. Delete the replicated logical volume on the destination (Secondary) NAS.
3. Extend the size of the source logical volume in primary NAS. Please note that there should be enough space on the VG of the destination NAS to accommodate the extended logical volume space. For example, if the size of source logical volume is now 3TB, the VG ("Remote VG") on the destination NAS must also have free 3TB space for creating the replicated logical volume (Note that after aborting replication, the same logical volume name can be deleted on the destination NAS to free up VG space).
4. Create a new Replication Backup using the extended logical volume on primary NAS.



NOTE:

Extending the size of a Logical Volume under Replication Backup is not allowed. However, there is a work around to extend the LV size. Note that the extended LV size must not exceed 16TB.

3.8.4 Snapshot Backup

Snapshot Backup creates a backup “copy” of a logical volume in specific moment in time. This feature is Block Level. Snapshot Backup also supports backup of iSCSI Target Volume and FC Target Volume, including scheduled backup.

Snapshot Backup						
➕ Add ✎ Edit ✖ Delete 🔄 Refresh						
Plan Name	Size(GB)	Numbers	Logical Volume	Logical Volume Type	Volume Group Name	VG Free Size(GB)
LV_1_snapshot	1	5	LV_1	logic volume	VG01	7275
Snapshot Record						
Plan Name	Logical Volume	Create Time	Snapshot Name	Usage(%)	Status	

Figure 3.8.4-1 Snapshot Backup List

Add Snapshot: Click the 'Add' icon. The Add Snapshot window will appear. Enter the necessary information. Click 'OK' when done.

Add Snapshot

Logical Volume:

LV_1

Plan Name:

LV_1_snapshot

Numbers:

5

Setting Size(GB):

1

Logical Volume Type:

logic volume

LV Free Size(GB):

10

Volume Group Name:

VG01

VG Free Size(GB):

7275

OK

Cancel

Figure 3.8.4-2 Create a New Snapshot Backup Plan

Logic Volume: Select the logical volume name that will be used to create Snapshot Backup.

Plan Name: Enter the name of the Snapshot Backup plan. The plan name can be up to 32 characters, and can contain only letters, numbers, hyphen (-), or underscore (_). Space or period (.) is not allowed. Duplicate plan name is also not allowed.

Numbers: This is the maximum number of snapshots. Default is 5. If the maximum number of snapshots is reached, for example there are now 5 snapshot backup, the next/newest snapshot will automatically overwrite the first/oldest snapshot.

Setting Size (GB): This is the capacity that will be used in each snapshot backup. If the amount of data in the logical volume exceeds the capacity that will be used for the snapshot, the snapshot backup will fail and can't be used. In order to avoid such case, it is advisable to set the snapshot capacity (Setting Size) the same as logical volume size.

Logic Volume Type: The system will automatically detect the type of logical volume, such as Default Volume, Logical Volume, Replication Volume, iSCSI Volume, or FC Volume (5 types). This information is for reference only and cannot be changed.

LV Free Size (GB): This is capacity of the selected logical volume. This information is for reference only and cannot be changed.


Volume Group Name: This is the volume group name where the selected logical volume was created. This information is for reference only and cannot be modified.


VG Free Size (GB): This is the free space of the volume group name where the selected logical volume exists. This information is for reference only and cannot be modified.



NOTE: If a logical volume is already used for Snapshot Backup, the logical volume can no longer be used to create another snapshot backup plan. Only one snapshot backup plan is allowed to be created in a logical volume.

Edit Snapshot: Select the Snapshot Backup plan name you want to edit and click the 'Edit' icon. The Edit Snapshot window will appear. Only the "Numbers" and "Setting Size (GB)" can be modified. Click 'OK' when done. The changes will be updated to the snapshot backup plan.

Delete Snapshot Backup Plan: Click the delete icon  on the right of the snapshot backup plan name to be deleted. The Confirm window will appear. Select the 'Yes' button to confirm deletion.

Delete Snapshot Backup Record: Click the delete icon  on the right of the snapshot backup record to be deleted. The Confirm window will appear. Select the 'Yes' button to confirm deletion.




Figure 3.8.4-3 Confirm Message to Remove a Snapshot Backup Record

Restore Snapshot: Select the Plan Name that has the snapshot backup to be restored. The previous snapshot backups will appear in the Snapshot Record list. Click the 'Restore' icon on the right of the snapshot backup to be restored (Figure 3.8.4-4). The Snapshot Restore window will appear (Figure 3.8.4-5).



NOTE: Only snapshot backups of logical volumes can be restored. Snapshot backups of iSCSI volumes or FC volumes cannot be restored. However, there is a work around in order to access the data from snapshot backup, and that is to create an iSCSI or FC target volume using the snapshot backup volume (of the iSCSI volume or FC volume), and then connect the client computer to the iSCSI or FC target volume.

2 Options for Restore:

Select **"Select File Restore"** to restore specific files or folders only and click 'OK'. The Confirm window will appear (Figure 3.8.4-7). Click 'Yes'. The Restore Snapshot window will appear (Figure 3.8.4-8). Select the folder or file you want to be restored, choose the Destination folder and click 'Restore'. Data will be restored to the Destination folder.

Select **"Full Volume Restore"** and click 'OK'. The Confirm window will appear (Figure 3.8.4-6). Click 'Yes' to restore full volume data.

Snapshot Backup						
<div> Add Edit Delete Refresh </div>						
Plan Name	Size(GB)	Numbers	Logic Volume	Logic Volume Typ	Volume Group Na	VG Free Size(GB)
share_snapshot	1	5	share	logic volume	VG01	2284
Snapshot Record						
Plan Name	Logic Volume	Create Time	Snapshot Name	Usage(%)	Status	
share_snapshot	share	2012-09-13 11:41:...	share_snapshot_20...	0	active	
share_snapshot	share	2012-09-13 11:41:...	share_snapshot_20...	0	active	

Figure 3.8.4-4 Snapshot Record List



Figure 3.8.4-5 Snapshot Restore Option




Figure 3.8.4-6 Confirm Message of Full Volume Restore Snapshot



Figure 3.8.4-7 Confirm Message to Restore Snapshot




Figure 3.8.4-8 Select Share Folder or File to Restore

The Snapshot backup plan can also be defined with scheduled job in Schedule manager. (See Chap 3.4.8)

3.8.5 Volume Clone

Volume Clone can create fast replicate copy of one volume locally. One copy and up to three copies can be created.

Clone Status: Status of clone job. If it shows Ready, a new clone can be created.

Step 1: Select Clone Source: Select the original volume which can be general data volume, iSCSI or FC volumes. (Figure 3.8.5-1)

Step 2: Select Clone Destination: Select volume group to create the new volume clone copy, define the name of new volume clone. If you want to clone more than one copy, Click "**Add**" (Figure 3.8.5-2). The maximum number of clones is 3.

After configure, click "**Start**". The system will start cloning the volume after confirming the Clone Summary (Figure 3.8.5-3).

While cloning, you can see the volume clone status (Figure 3.8.5-4).



NOTE: Snapshot and Thin Provisioning volumes do not support cloning.

Volume Clone

Status

Clone Status: Ready

Step 1. Select Clone Source

Logical Volume: Select one item

(

Volume Group:

Type:

Size:

)

Step 2. Select Clone Destination

Add

Volume Group: VG01

Logical Volume:


Start

Clone Log


Date/ Time	Type	Level	Client ID	Client IP	Message
------------	------	-------	-----------	-----------	---------

Figure 3.8.5-1 Clone Manager

Setp 2. Select Clone Destination

 Add

Volume Group: Logical Volume:

Volume Group: Logical Volume: 


Volume Group: Logical Volume: 

Figure 3.8.5-2 Clone More Than One Copy

Clone Summary

Source

Volume Group: VG01 **Logical Volume:** LV_6

Destination

Volume Group: VG01 **Logical Volume:** LV6Clone1

Volume Group: VG01 **Logical Volume:** LV6Clone2

Volume Group: VG01 **Logical Volume:** LV6Clone3






 

Figure 3.8.5-3 Confirm Message to Clone Volume

Volume Clone

LV_6 to LV6Clone1: 

LV_6 to LV6Clone2: 


LV_6 to LV6Clone3: 

Setp 1. Select Clone Source


Logical Volume:


(**Volume Group:** VG01 **Type:** logic volume **Size:** 10 GB)


Setp 2. Select Clone Destination

 Add

Volume Group: Logical Volume:

Volume Group: Logical Volume: 

Volume Group: Logical Volume: 




Clone Log

Date/ Time	Type	Level	Client ID	Client IP	Message
2013-05-15 16:18:04	Backup	INFO	admin	192.168.100....	Volume Clone LV6Clone3:Cloned successfully
2013-05-15 16:17:57	Backup	INFO	admin	192.168.100....	Volume Clone LV6Clone2:Cloned successfully
2013-05-15 16:17:50	Backup	INFO	admin	192.168.100....	Volume Clone LV6Clone1:Cloned successfully

Figure 3.8.5-4 The Status after Clone Volume

3.8.6 Rsync Backup

Rsync is one of the popular remote backup solutions. Admin can use Rsync to upload whole local share to remote share or download files from remote share. You can create an Rsync backup plan by clicking "Add" button.



Rsync Backup						
Add Edit Delete Refresh						
Plan Name	Destination	Backup Mode	Last Backup Time	Next Backup Time	Status	
rbk1	192.168.100.120	upload	--	--	Enable	▶ ⛔

Figure 3.8.6-1 Rsync Backup

To add a new Rsync backup plan, the following need to be defined:

Plan Name: The name of Rsync plan. The name must be unique.

Local Share Folder

Share Folder: Select local share to do upload or download

Remote Share Folder

IP: the remote Rsync server IP

Account: the remote login name

Password: the login password

Path: The name or path of remote share

Mode: Specify to upload or download

Parameter: You can also define your own Rsync parameter here. Click ". . ." button to setup additional options.

Add

Plan Name:

Local Share Folder

Share Folder:

Remote Share Folder

IP:

Account:

Password:


Path:

Path Ex:

Mode:

Parameter:

Figure 3.8.6-2 Options to Create Rsync Backup Plan

After Rsync backup plan is created, you will see the new plan in the list. If need to modify Rsync options, just select the plan and click 'Edit'.
To immediately do Rsync backup, click icon  in the right column.

The Rsync backup plan can also be defined with scheduled job in Schedule manager. (See Chap 3.4.8)


3.8.7 System Configuration

System Configuration Backup can backup whole system configuration including Array, volumes, shares and accounts. You can import the backup configuration file to reconstruct the NAS configuration as before.

Configuration Backup: Click "Backup" button to backup the latest system configuration and create a backup configuration file, for example nas-config.tgz.

Configuration Restore: Click "Select File" to select a backup configuration file to restore.

Before restore, the system must be started with factory default settings and without Array or volume.



The screenshot shows a web interface titled "System configuration". It is divided into two main sections. The first section, "Configuration Backup", contains the text "Backup System Configuration" and a "Backup" button. The second section, "Configuration Restore", contains the text "Restore System Configuration". Below this text, there is a label "Configuration File:" followed by a text input field and a "Select File..." button. At the bottom of this section is a "Restore" button.

Figure 3.8.7-1 System Configuration Backup and Restore

3.8.8 Amazon S3


Amazon S3 (Simple Storage Service) is provided by the Amazon Pay online storage services. NAS users through support for Amazon S3 to backup your important data to Amazon S3, or download the data from Amazon S3 and to the NAS. Addition, users can also function with built-in scheduler to set automatic backup task

Amazon S3						
 Add	 Edit	 Delete	 Refresh			
Plan Name	Transfer type	Bucket	Last Backup Time	Next Backup Time	Status	

 Show All Plan Backup Record					
Plan Name	Start Time	Finish Time	Local	Result	

Figure 3.8.8-1 Amazon S3

Add Amazon S3 backup plan: To add a new Amazon S3 backup plan, the following need to be defined.



The dialog box titled "Add" contains the following fields and controls:

- Plan Name:** A text input field with a "Check" button to its right.
- Transfer type:** A dropdown menu currently showing "Upload".
- Local Share:** A dropdown menu currently showing "Select one item".
- Amazon S3 Setting:** A section containing:
 - Access Key:** A text input field.
 - Secret Key:** A text input field.
 - Bucket:** A dropdown menu currently showing "Select or Create New".
- Buttons:** "OK" and "Cancel" buttons at the bottom right.

Figure 3.8.8-2 Add Amazon S3

Plan name: Amazon S3 project name, the name must be unique.

Transfer type: upload or Download Select local shared upload or download

Local Folder: Select the files needed to synchronize local folder

Amazon S3 information:

Access key: enter the access key

Secret key: Enter the passkey

Bucket: When you have entered the correct information, you will be imported into your account. Or create a new "Create New" and enter the bucket name, for example: backup. Be created in any folder under the root directory is your buckets. Your bucket name must be unique, meaning that all other users of the S3 bucket differently. All files and folders will be stored in buckets in.

Get Amazon S3 account

Step 1: Registration Amazon Web Services account

Before using this service, you need to first obtain a personal Amazon S3 account (<http://aws.amazon.com/s3/>). For details about the fees, see the Amazon web services website.

Step 2: Get your Access Key ID and Secret Access Key

When you have completed the account application process, you will receive part of your Access Key ID and Secret Access Key. Please keep this ID and key.

If you accidentally lost your Access Key ID and Secret Access Key, please click on "Your Account" and select "Security Credentials" to regain.



You can use the "Your Account" option at any time to review your account status, payment information, and change your personal information.

3.9 Attached Device Manager



3.9.1 Physical Device

When USB or eSATA storage device is attached to the NAS, the NAS detects it as Physical Device (Figure 3.9.1-1). This device can be mounted and exported as a Samba share folder (Figure 3.9.1-4). The detected device is also available as backup destination.




Figure 3.9.1-1 Physical Device Manager




Figure 3.9.1-2 Format Attached Device

Format: The device can be formatted with NTFS, EXT3 or EXT4 file system.

Mount: If system recognized the file system in the attached device, it can be mounted as Samba share folder.

Unmount: Un-mount the device. The device will no longer be defined in Samba service.




Figure 3.9.1-3 Mount and Share Attached Device



Figure 3.9.1-4 If Mounted, Attached Device can be Accessed from Windows Clients



NOTE: Please make sure the device is un-mounted before it is deattached from NAS unit.

3.9.2 ISO Mount

You can pick an ISO file in NAS then mount and export it as a Samba share (Figure 3.9.2-4).

Add: Click to select a ISO File in the list. (See Figure 3.9.2-2)

Delete: Remove the ISO File from list.

Mount: Mount the ISO File and share it to a Samba share list (See Figure 3.9.2-3)

Unmount: Unmount the ISO File and remove from Samba share list




Figure 3.9.2-1 ISO Mount




Figure 3.9.2-2 Select ISO file




Figure 3.9.2-3 Mount and Share ISO File




Figure 3.9.2-4 ISO Share in Samba

3.9.3 iSCSI Initiator

iSCSI Initiator allow admnb to connect to iSCSI target, mount iSCSI volume, format and export it as a Samba share (Figure 3.9.3-5)




Figure 3.9.3-1 iSCSI Initiator

Host List: (See Figure 3.9.3-1)

List All known iSCSI host list

Button in Host list

Add: Assign a new iSCSI host in list.

Delete : Remove a host from list

Initiator IQN: Some iSCSI target require IQN to logon. Enter the IQN for the iSCSI host

After adding host, the target(s) will be displayed in the Targets List on the right.

Target List (See Figure 3.9.3-1)

List all targets from Hosts List.

Logon : Logon to Target and get all iSCSI disks list. (See Figure 3.9.3-2)

Logoff : Logoff from Target and release all iSCSI disks.

Refresh: Refresh the target list.




Figure 3.9.3-2 Log on iSCSI Target

After logon target successfully, all iSCSI Disks will be shown in the Disks List. (Figure 3.9.3-3)

Format: Format the iSCSI disk with EXT3, EXT4 or NTFS. (See Figure 3.9.3-4)

Mount: Mount the iSCSI disk and show in Samba share list. (See Figure 3.9.3-5)

Unmount: Unmount iSCSI disk and remove from Samba share list.




Figure 3.9.3-3 Disks List from iSCSI Target




Figure 3.9.3-4 Format the iSCSI Disk





Figure 3.9.3-5 iSCSI Disk Share in Samba

3.10 Plug-in Manager



The Plug-in Manager is for installing other software like backup agent, HA services, etc.

Current Plug-in modules are CA ARCserve Backup Agent, NetVault Backup Agent, Symantec Backup Exec Agent, CDP Agent and HA.

How To install

Please ask your vendor to get the latest plug-in modules.

Go to Plug-in Center and click "**Add Plug-in Application**" button at the upper right side (Figure 3.10.1).

Choose what plug-in (Figure 3.10.2) to install then select plug-in file (Figure 3.10.3) to upload and install.

While installing, the status will be shown as Figure 3.10.4, After install successful the new service will show up in Plug-in center (Figure 3.10.5).




Figure 3.10-1 Plug-in Manager




Figure 3.10-2 Choose and Add Plug-in Application




Figure 3.10-3 Select Plug-in File to Install




Figure 3.10-4 Status of Installing a Plug-in Application




Figure 3.10-5 Plug-in Service Status after Install




Figure 3.10-6 Register or use Trial Version (Trial Period)

After Backup Agents is installed, it needs a related backup server to connect to. Please contact the vendor of backup server for more information.

Register:

Some modules like CDP and HA needs to be registered (Figure 3.10.6). Please contact the NAS vendor to get detailed information. You can test the functions as a "Trial" version, and allows you to test within 30 days trial period.



NOTE: Installing un-official Plug-in modules is not allowed.

3.10.1 NAS HA

What's NAS HA?

NAS HA (High Availability) cluster provides solution for business continuity with real time, continuous data replication and synchronization, which ensures that if ever one NAS server/node becomes unavailable, due to failure or maintenance-related downtime, the remaining NAS server/node can still provide all services to client computers.

NAS HA can have 2-node HA cluster or 3-node HA cluster. All nodes in HA cluster are active. This means in a 2-node HA cluster, for example NAS-1 and NAS-2, resources from each node, such as NAS share folders, are accessible in both nodes. In 3-node HA cluster, all 3-nodes resources are also accessible in all 3 nodes.

NAS HA Architecture




Figure 3.10.1-1 Two-nodes HA Cluster

In 2-node HA cluster, Logical Volumes in NAS-1 are replicated to NAS-2, and Logical Volumes of NAS-2 are replicated to NAS-1.




Figure 3.10.1-2 Three-nodes HA Cluster

In 3-node HA cluster, Logical Volumes in NAS-1 are replicated to NAS-2, Logical Volumes of NAS-2 are replicated to NAS-3, and Logical Volumes of NAS-3 are replicated to NAS-1.

NAS HA Setup Steps:

Configure NAS Host Names → Configure Network Settings → Configure Logical Volumes and Share Folders → → Install NAS HA Plug-in → Setup HA and Start HA Service



NOTE: The VG (Volume Group, such as VG01) in each NAS nodes must have enough VG free space for other NAS node to replicate Logical Volumes. Check the size of Logical Volumes from each NAS node.

1. Configure NAS Host Names

In System Manager -> General -> GUI -> Host Name, change NAS host name.




Figure 3.10.1-3 NAS Host Name



NOTE: The Host Name of NAS nodes cannot be the same, i.e., each NAS Host Name must be unique.

2. Configure Network Settings

In System Manager -> Network, configure LAN_0 and LAN_1 (default LAN ports).

NAS HA service needs 2 LAN interfaces:

Public IP - for NAS configuration, also for client access

Private IP – for HA replication and heartbeat




Figure 3.10.3-4 Configure Network Settings

Please see **Section 3.4.2 Network** for more information to configure IP address.

3. Configure Logical Volumes and Share Folders

Each NAS node requires least one Logical Volume to run HA.

In NAS GUI of one NAS node, go to Storage Manager -> Volume Group -> VG name (example: VG01), create Logical Volume, for example "LV_1". In Storage Manager -> Share, create share folder under the Logical Volume, for example "share01". In the other NAS node, create different Logical Volume name and Share Folder name.

Figure 3.10.1-5 Add Logical Volume

Please refer to **Chapter 3.5 Storage Manager** for more information to configure LV and Share Folder.



NOTE: The Logical Volume names and Share Folder names can't be the same between nodes. For example, if NAS-1 has Logical Volume LV_1, then LV_1 must not exist in other NAS nodes, such as in NAS-2, or in NAS-3 (in case of 3-node HA cluster). If Share Folder "share01" is created in NAS-1, other NAS nodes cannot use same share folder name.



NOTE: When creating Logical Volumes, need to consider the size of the Logical Volume and the VG free space on the other NAS node. For example, in 2-node HA, NAS-1 has 5TB LV_1, and NAS-2 has 10TB LV_2. NAS-1 VG must have 10TB free space for LV_2 to replicate, and NAS-2 VG must have 5TB free space for LV_1 to replicate.

4. Install NAS HA Plug-In

When using NAS HA Cluster service, you need to install NAS HA Plug-in in each NAS node that will be included in cluster.

Steps:

- a. Expand Plug-In Manager, and click "Plug-In Center".




Figure 3.10.1-6 HA Plug-In Center

- b. Click the "Add Plug-In Application" to start the installation wizard.




Figure 3.10.1-7 Add Plug-In Application

- c. Click the “Install” button of HA item.




Figure 3.10.1-8 Install HA Plug-in

- d. Click the “Browse” button to select the plug-in file, and click OK.




Figure 3.10.1-9 Select the HA Plug-in File

- e. Installation is complete, click “Yes”.




Figure 3.10.1-10 HA Plug-in Installation Done

- f. You can select Trial, or Register and provide the license key file.




Figure 3.10.1-11 Select Trial or Register




Figure 3.10.1-12 HA in Trial Period

5. Setup NAS HA and Start HA Service

- a. Please expand Plug-In Manager, and click into "HA" page.




Figure 3.10.1-13 HA Plug-In

HA

Cluster List

Cluster Name:	N/A
Cluster Status:	N/A
Member:	N/A
Keep Alive Time:	N/A
Retry Heartbeat :	N/A
Auto Fail Back:	N/A
<input type="button" value="Start HA Cluster"/>	

Replication Status

Host Name	Public IP	Virtual IP	Private IP	Status
No data to display				

Page 0 of 0

Free Host List

Host Name	IP Address	Free Size	Used Size	Version	Model
NAS-61	10.10.20.61	1716	128	3.0.01	EN-2126JS6T-SQX
NAS-62	10.10.20.62	1715	128	3.0.01	EN-3163S6T-RQX
NAS-63	10.10.20.63	1715	128	3.0.01	EN-3163S6T-RQX

Page 1 of 1

Displaying 1 - 3 of 3

Figure 3.10.1-14 HA Setup Page

- b. Click "HA Cluster Quick Setup"




Figure 3.10.1-15 HA Cluster Quick Setup

- c. Select NAS host names that will be included in HA cluster. Click Next.

The "Add HA Cluster" dialog box is shown with the "Select Host" tab active. It features a sidebar with "Select Host", "Cluster Setting", and "Conclusion". The main area displays cluster details: "Cluster Name: Cluster01", "Transmit Speed(Mb/sec): 100", and "Cluster Status: Stop". Below this is a "Free Host List" table with three rows, each checked. The table has columns for Host Name, IP Address, Free Size, Used Size, Version, and Model. At the bottom right are "Previous", "Next", and "Cancel" buttons.

	Host Name	IP Address	Free Size	Used Size	Version	Model
<input checked="" type="checkbox"/>	NAS-61	10.10.20.61	1716	128	3.0.01	EN-2126JS6T-SQX
<input checked="" type="checkbox"/>	NAS-62	10.10.20.62	1715	128	3.0.01	EN-3163S6T-RQX
<input checked="" type="checkbox"/>	NAS-63	10.10.20.63	1715	128	3.0.01	EN-3163S6T-RQX

Figure 3.10.1-16 Select NAS Host Names

d. In Cluster Setting, setup the following:

Reference Node: IP address of other host or device on the network used to verify NAS network access or connectivity, such as domain server IP address or gateway IP address.

Virtual IP: Cluster IP address for client's access. Use the Virtual IP address to access Cluster resources, such as share folders of NAS nodes.

Public IP - for NAS configuration, also for client access

Private IP – LAN port for HA replication and heartbeat

Add HA Cluster

Cluster Setting

Keep Alive Time(second): 2 Reference Node1: 10.10.20.1

Retry Heartbeat (time): 6 Reference Node2: 10.10.20.2

Auto Fail Back: ☒ Yes ☐ No

Host Name: NAS-61

Public IP: 10.10.20.61 Private IP: 10.99.99.61

eth0 eth1

Virtual IP: 10.10.20.201

Host Name: NAS-62

Public IP: 10.10.20.62 Private IP: 10.99.99.62

eth0 eth1

Virtual IP: 10.10.20.202

Host Name: NAS-63

Public IP: 10.10.20.63 Private IP: 10.99.99.63

eth0 eth1

Virtual IP: 10.10.20.203

Previous Next Cancel

Figure 3.10.1-17 HA Cluster Setting

- e. In "Conclusion page" verify all settings are correct and click "OK".

Add HA Cluster

Conclusion

Cluster Name: Cluster01 Transmit Speed(Mb/sec): 100

Keep Alive Time(second): 2 Reference Node1: 10.10.20.1

Retry Heartbeat (time): 6 Reference Node2: 10.10.20.2

Auto Fail Back: Yes

Selected Host

Host Name	Public IP	Virtual IP	Private IP
NAS-61	10.10.20.61	10.10.20.201	10.99.99.61
NAS-62	10.10.20.62	10.10.20.202	10.99.99.62
NAS-63	10.10.20.63	10.10.20.203	10.99.99.63

Previous Next OK

Figure 3.10.1-18 Conclusion Page

- f. Confirm setting, and select "Start Cluster after creating cluster configuration" to automatically start HA service.

Confirm

? Start Cluster **Cluster01**

Confirm: ☒

Start cluster after creating cluster configuration?: ☒

Yes No

Figure 3.10.1-19 Confirm and Automatically Start HA Cluster

- g. Cluster setup will be created. Please wait for several minutes (5 to 15 minutes).

Add HA Cluster

Adding cluster. Please wait 5 to 15 minute.

Setting synchronous home...

Progress bar: []

Figure 3.10.1-20 Adding Cluster

- h. Logical Volumes in each node will be synchronized to other NAS node(s) and will show progress status "Initializing".




Figure 3.10.1-21 HA Cluster Initializing



NOTE: While the HA setup is initialized and Logical Volumes in each NAS node is synchronized to other node(s), the Sync status can be verified in Backup Manager -> Replication Backup.




Figure 3.10.1-22 Sample Replication Sync Status of Logical Volumes



NOTE: If Logical Volumes is not yet finished synchronizing to other NAS node and one NAS node fails, the HA Fail-Over function will not work properly.

- i. When synchronization is complete, status will show “active”. HA service is working properly.

The screenshot displays the HA Cluster Status interface. At the top, three nodes are shown with their status as 'active':

- EN-316356T-RQX 10.10.20.62
- EN-2126356T-SQX 10.10.20.61
- EN-316356T-RQX 10.10.20.63

On the right, cluster details for 'Cluster01' are listed:

- Cluster Name: Cluster01
- Cluster Status: active
- Member: 3
- Keep Alive Time: 2
- Retry Heartbeat: 6
- Auto Fail Back: true

Below this, a table shows the replication status for the cluster:

Host Name	Public IP	Virtual IP	Private IP	Status
Cluster Name: Cluster01				
NAS-62	10.10.20.62	10.10.20.202	10.99.99.62	✓
NAS-61	10.10.20.61	10.10.20.201	10.99.99.61	✓
NAS-63	10.10.20.63	10.10.20.203	10.99.99.63	✓

Figure 3.10.1-23 HA Cluster Status is Active



NOTE: When NAS nodes status show “active”, it means HA is working. One NAS node can fail and the other NAS node can still provide the resources from failing NAS node after fail-over.

HA Fail-Over

When one NAS node becomes unavailable, due to some problem such as hardware failure, there is about 5 minutes fail-over time for the Virtual IP of failing NAS node. After about 5 minutes, the remaining NAS node will have taken over, and the Virtual IP of the failing NAS node will become accessible again.

Fail-Over Scenario

When one NAS node fails, the other NAS node will take over. In the example below with 3-node HA cluster, when server A fails, after fail-over to server B, the resources (i.e. Logical Volumes and share folders) from server A will be accessible again from server B. Connect/access using the same Virtual IP of server A.




Figure 3.10.1-24 Three-node HA Cluster




Figure 3.10.1-25 One Node Failed in HA Cluster

Testing HA Fail-Over

HA Fail-Over can be tested by:

1. Shutdown one NAS node
2. Power off one NAS node
3. Remove LAN cables from one NAS node

3.11 File Manager

File Manager is a web-based tool used to manage files and folders under a share. The service is enabled by default. It can be disabled in Service Manager. If File Manager service is enabled, all NAS users can logon NAS GUI via web browser and use File Manager for quick maintenance of files (Figure 3.11-1). By default, if admin login NAS GUI, he will be shown with the NAS management GUI. If admin wants to switch to File Manager, click the small File Manager icon on the upper right side, on the right side of "**System Log**" icon (Chap 3.2).

In the File Manager, all functions are listed in right top menu. File Manager allows NAS users to do file editing like upload(Figure 3.11-8), download, delete(Figure 3.11-3), rename(Figure 3.11-4), copy (Figure 3.11-6) or move(Figure 3.11-7). Just need to make sure the NAS user have read and write permission.




Figure 3.11-1 File Manager




Figure 3.11-2 Create a New Folder




Figure 3.11-3 Delete a File




Figure 3.11-4 Rename a File




Figure 3.11-5 Change File Owner




Figure 3.11-6 Copy a File to Selected Destination Folder




Figure 3.11-7 Move a File to Select Destination Folder




Figure 3.11-8 Upload a File




Figure 3.11-9 Change File or Folder Permission

If the NAS user account currently logged on in File Manager is the share owner, he can change file or folder permission (See Figure 3.11-9) under the share.




Figure 3.11-10 Change User Password

If NAS users want to change their password, they can logon to File Manager to change their password. This function is only for local NAS user accounts (Figure 3.11-10).

3.12 General Limitation List

Here are some basic limitations list below.

GUI

Admin login	Single Admin login
Shortcut bar icon	Max :9

System Manager

NIC ports	Max: 8
Trunk device	Max: 4
Event Email Receiver	Max: 8

Storage Manager

Array Number	Max: 64
Volume Group Number	Max: 64
Logical Volume Number	Max: 512
Logical Volume Size	Max: 16 TB for ext3 1000 TB for others
Logical Volume with Thin Provision Size	Min: 50GB Max: 32 TB or Logical Volume Size x 4

iSCSI Target

Target Number	Max: 64
Connections	Max: 32
Volumes per Target	Max: 256
Initiators ACL per target	Max: 32

FC Target

Target Number	Max: 8
Volumes per Target	Max: 256
WWN ACL per target	Max: 32

Share

Number	Max: 512
ACL per share	Max: 64

Account

Number	Max: 20000
--------	------------

Group

Number	Max: 20000
Member in group	Max: 200

Backup

Plan Number	Max: 128
Snapshots per volume	Max: 8
Snapshot Total Number	Max: 256

File Manager

Max node number in Tree	10000
Max node number in List	10000
Upload single file size	Max:5GB